AIR-HANDLER AIR CONDITIONER


ΕN

Installation Manual

Safety precutions & Installation

ComfortStar®

Indoor Unit: AHU18-SG2 AHU24-SG2 AHU30-SG2 AHU36-SG2 AHU48-SG2 AHU60-SG2 Outdoor Unit: CPR18CD(O) CPR24CD(O) CPR30CD(O) CPR36CD(O) CPR48CD(O) CPR60CD(O)



IMPORTANT NOTE:

Read this manual carefully before installing or operating your new air conditioning unit. Make sure to save this manual for future reference.



INSTALLATION MANUAL

SAFETY PRECAUTIONS	02
ACCESSORIES	06
INDOOR UNIT INSTALLATION	07
REFRIGERANT PIPING CONNECTION	17
INSTALLATION OF ELECTRIC AUXILIARY HEAT MODULE (ONLY FOR HEAT FUNCTION MODELS)	21
CONFIRMATION OF INDOOR UNIT	23
OUTDOOR UNIT INSTALLATION	27
WIRING	31
SPECIFICATION	43
AIR EVACUATION	44
NOTE ON ADDING REFRIGERANT	45
TEST RUN	46

Read this manual

Inside you'll find many helpful hints on how to use and maintain your air conditioner properly. Just a little preventive care on your part can save you a great deal of time and money over the life of your air conditioner. These instructions may not cover every possible condition of use, so common sense and attention to safety is required when installing, operating and maintaining this product.

SAFETY PRECAUTIONS

Intended Use

The following safety guidelines are intended to prevent unforeseen risks or damage from unsafe or incorrect operation of the appliance. Please check the packaging and appliance on arrival to make sure everything is intact to ensure safe operation. If you find any damage, please contact the retailer or dealer. Please note modifications or alterations to the appliance are not allowed for your safety. Unintended use may cause hazards and loss of warranty claims.

Explanation of Symbols



WARNING

The signal word indicates a hazard with a medium level of risk which, if not avoided, may result in death or serious injury.



CAUTION

The signal word indicates a hazard with a low degree of risk which, if not avoided, may result in minor or moderate injury.



NOTICE

The signal word indicates important information (e.g. damage to property), but not danger.

Read these operating instructions carefully and attentively before using/commissioning the unit and keep them in the immediate vicinity of the installation site or unit for later use!



This appliance is not intended for use by persons(including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

WARNINGS FOR PRODUCT USE

- If an abnormal situation arises (like a burning smell), immediately turn o the unit and disconnect the power. Call your dealer for instructions to avoid electric shock, fire or injury.
- **Do not** insert fingers, rods or other objects into the air inlet or outlet. This may cause injury, since the fan may be rotating at high speeds.
- **Do not** use flammable sprays such as hair spray, lacquer or paint near the unit. This may cause fire or combustion.
- **Do not** store gasoline or flammable substances near air conditioner. Emitted gas may collect around the unit and cause explosion.
- <u>Do not</u> install your air conditioner in a wet room such as a bathroom or laundry room. Too much exposure to water can cause electrical components to short circuit.
- Do not expose your body directly to cool air for a prolonged period of time.
- Do not allow children to play with the air conditioner. Children must be supervised around the unit at all times.
- If the air conditioner is used together with burners or other heating devices, thoroughly ventilate the room to avoid oxygen deficiency and carbon monoxide build up.
- In certain environments, such as kitchens, server rooms, etc., the use of specially designed air-conditioning units is highly recommended.
- Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Installation and service must be performed by a licensed professional HVAC installer or equivalent, service agency, or the gas supplier.

⚠ CAUTION

- Turn o the air conditioner and disconnect the power if you are not going to use it for a long time.
- Make sure that water condensation can drain unhindered from the unit.
- Do not operate the air conditioner with wet hands. This may cause electric shock.
- Do not use device for any other purpose than its intended use.
- **Do not** climb onto or place objects on top of the outdoor unit.
- <u>Do not</u> allow the air conditioner to operate for long periods of time with doors or windows open, or if the humidity is very high.
- As with any mechanical equipment, contact with sharp sheet metal edges can result in personal injury. Take care while handling this equipment and wear gloves and protective clothing.

A ELECTRICAL WARNINGS

- The product must be properly grounded at the time of installation, or electrical shock may occur.
- For all electrical work, follow all local and national wiring standards, regulations, and the Installation Manual. Connect cables tightly, and clamp them securely to prevent external forces from damaging the terminal. Improper electrical connections can overheat and cause fire, and may also cause shock. All electrical connections must be made according to the Electrical Connection Diagram located on the panels of the indoor and outdoor units.
- All wiring must be properly arranged to ensure that the control board cover can close properly. If the control board cover is not closed properly, it can lead to corrosion and cause the connection points on the terminal to heat up, catch fire, or cause electrical shock.

• If connecting power to fixed wiring, an all-pole disconnection device which has at least 3mm clearances in all poles, and have a leakage current that may exceed 10mA, the residual current device(RCD) having a rated residual operating current not exceeding 30mA, and disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.

▲ WARNINGS FOR PRODUCT INSTALLATION

- Installation must be performed by an authorized dealer or specialist. Defective installation can cause water leakage, electrical shock, or fire.
- Installation must be performed according to the installation instructions. Improper installation
 can cause water leakage, electrical shock, or fire.
 (In North America,installation must be performed in accordance with the requirement of NEC
 and CEC by authorized personnel only.)
- Contact an authorized service provider for repair or maintenance of this unit. This appliance shall be installed in accordance with national wiring regulations.
- Only use the included accessories, parts, and specified parts for installation. Using non-standard parts can cause water leakage, electrical shock, fire, and can cause the unit to fail.
- Install the unit in a firm location that can support the unit's weight. If the chosen location cannot support the unit's weight, or the installation is not done properly, the unit may fall and cause serious injury and damage.
- Install drainage piping according to the instructions in this manual. Improper drainage may cause water damage to your home and property.
- For units that have an auxiliary electric heater, do not install the unit within 1 meter (3 feet) of any combustible materials.
- <u>Do not</u> install the unit in a location that may be exposed to combustible gas leaks. If combustible gas accumulates around the unit, it may cause fire.
- Do not turn on the power until all work has been completed.
- When moving or relocating the air conditioner, consult experienced service technicians for disconnection and reinstallation of the unit.
 - How to install the appliance to its support, please read the information for details in "indoor unit
- installation" and "outdoor unit installation" sections .
- Excessive Weight Hazard Use two or more people when moving and installing the unit. Failure to do so can result in back or other type of injury.

MARNINGS FOR CLEANING AND MAINTENANCE

- Turn o the device and disconnect the power before cleaning. Failure to do so can cause electrical shock.
- **Do not** clean the air conditioner with excessive amounts of water.
- <u>Do not</u> clean the air conditioner with combustible cleaning agents. Combustible cleaning agents can cause fire or deformation.

NOTE ABOUT FUSE SPECIFICATIONS

- The air conditioner's circuit board (PCB) may be designed with a fuse to provide overcurrent protection. This fuse must be replaces with identical component.
- The specifications of the fuse, if equipped, are printed on the circuit board, examples of such are T5A/250VAC and T10A/250VAC.

NOTE ABOUT FLUORINATED GASSES (NOT APPLICABLE TO THE UNIT USING R290 REFRIGERANT)

- This air-conditioning unit contains fluorinated greenhouse gasses. For specific information on the type of gas and the amount, please refer to the relevant label on the unit itself or the "Owner's Manual Product Fiche" in the packaging of the outdoor unit. (European Union products only).
- Installation, service, maintenance and repair of this unit must be performed by a certified technician.
- Product uninstallation and recycling must be performed by a certified technician.
- When the unit is checked for leaks, proper record-keeping of all checks is strongly recommended.

The allowed static pressure range of the air conditioner on site is 0-0.80 in-H2O (0-200 Pa). The data below represents the static pressures at full required air flow used for AHRI testing.

MODEL	18-24K	30-36K	48-60K
PRESSURE (Before Jan,1,2023)	0.10 in-H2O(25Pa)	0.15 in-H2O(37Pa)	0.20 in-H2O(50Pa)
PRESSURE (After Jan,1,2023)	0.5 in-H2O(125Pa)	0.5 in-H2O(125Pa)	0.5 in-H2O(125Pa)

NOTE

The maximum functional total external static pressure can not exceed 0.80 in WC or 200 Pa. The airflow reduces significantly beyond 0.80 in WC or 200Pa. System design should allow for the increased resistance of filters as they become dirty.

ACCESSORIES

The air conditioning system comes with the following accessories. Use all of the installation parts and accessories to install the air conditioner. Improper installation may result in water leakage, electrical shock and fire, or equipment failure.

Accessories (Packed with the indoor unit)

Name	Picture	Quantity
Manual	Manual	3
Remote controller		1
Battery	9	2
Wired remote controller		1
Cable ties		2
Foam		4
Flare nut (optional)		2
Braze to flare adapter (optional)		2

Accessories-optional (Packed with the outdoor unit)

Name	Picture	Quantity
Drain fitting		1
Gasket		1

NOTICE

The wired system control functions as an IR receiver for the handheld remote, if the remote is not used it must be retained with the indoor unit to adjust parameters, and for troubleshooting.

INDOOR UNIT INSTALLATION

CAUTION -

Install the indoor and outdoor units, cables and wires at least 1m (3-1/5 $^{'}$) from televisions or radios to prevent static or image distortion. Depending on the appliances, a 1m (3-1/5 $^{'}$) distance may not be sull cient.

The Indoor unit must be electrically grounded per national and local electrical code.

Select the installation location of indoor units



WARNING DO NOT LOCATIONS:



DO NOT install the indoor unit in a moist environment. Excessive moisture can corrode the equipment, electrical components, and cause electrical shorts.



Areas with strong electromagnetic waves.



Coastal areas with high salt content in the air.



Areas with oil drilling or fracking.



Areas that store flammable materials or gas.



Areas where there may be detergent or other corrosive gases in the air, such as bathrooms, or laundry rooms.



Areas where the air inlet and outlet may be obstructed.



Danger of explosion. Keep flammable materials and vapors, such as gasoline, away from air handler.



WARNING MUST BE INSTALLED IN A LOCATION THAT MEETS THE FOLLOWING REQUIREMENTS:


A stable position



Securely install the indoor unit on a structure that can support its weight. If the structure is too weak, the unit may fall and cause personal injury, unit and property damage, or death.



- Enough room for installation and maintenance.
- ☑ Enough room for the connecting pipe and drainpipe.



Place air handler so that heating elements are at least 18 inches (46 cm) above the floor for a garage installation. Failure to follow these instructions can result in death, explosion, or fire.


Must support the weight of the indoor unit.

 $\ensuremath{\underline{\mathbf{m}}}$ The structure that the equipment is suspended from must support the weight of the indoor unit.

WARNING

There must be an airtight seal between the bottom of the air handler and the return air plenum. Use fiberglass sealing strips, foil duct tape, caulking, or equivalent sealing method between the plenum and the air handler cabinet to ensure a tight seal. Return air must not be drawn from a room where this air handler or any gas-fueled appliance (i.e., water heater), or carbon monoxide-producing device (i.e., wood fireplace) is installed.

Preparation and precautions for indoor unit installation



WARNING

- Please apply sealant around the places where the wires, refrigerant pipes and condensate pipes enter the cabinet.
- Use duct tape or flexible sealant to seal closed anyspace around the holes where the drain lines exit the cabinet. Warm air must not be allowed to enter throughany gaps or holes in the cabinet.




NOTICE

 Remove all accessories and packing in the air outlet before installation.

Recommended Distances Between the Indoor Unit

The distance between the mounted indoor unit should meet the specifications illlustrated in the following diagram.

Horizontal installations




The outlet side pipe length 1.5m/59".


Vertical installations



Fixing instructions: When installed vertically (upward or downward), the lower end of the air outlet needs to be connected to the L-shaped metal air duct and fastened by screws.

Indoor unit parts installation size





(unit: mm/inch)


Model A

Model(I Dimensions	Btu/h)	12K~24K	30K~48K	60K
Length of A	mm	1143	1245	1346
Longinor	inch	45	49	53
Length of B	mm	533	533	533
Lengthorb	inch	21	21	21
Length of C	mm	445	534	622
Lengthore	inch	17-1/2	21-1/50	24-1/2
Length of D	mm	400	490	580
Length of D	inch	15-3/4	19-5/16	22-27/32
Length of E	mm	260	260	260
Lenguiole	inch	10-1/4	10-1/4	10-1/4

Model B

Model(Dimensions	60K	
Length of A	mm	1245
Longth of 7t	inch	49
Length of B	mm	533
Lengurorb	inch	21
Length of C	mm	534
Lengthore	inch	21-1/50
Length of D	mm	490
Lengthold	inch	19-5/16
Longth of E	mm	260
Length of E	inch	10-1/4


Recommended size of filter




(unit: mm/inch)

Model(Btu/h	18K-24K	30K-48K	60K	
Length of W	mm	406.4	495.3	584.2
g	inch	16	20	23
Length of D	mm	508	508	508
Longinor	inch	20	20	20
Length of t	mm	25.4	25.4	25.4
Longinori	inch	1	1	1

Installation Position Requirements





Horizontal installations

• NOTICE FOR DUCT CONNECTIONS:



It should be assembled accordance to the instructions.



It should be insulated and use a Vapor Barrier.



It should be Flexible suspension mounted and not fastened



It should be fabricated and installed in accordance with local and/or national codes.

More Requirements

- Air supply and return may be handled in one of several ways best suited to the installation (See table
 for dimensions for duct inlet and outlet connections). The vast majority of problems encountered
 with combination cooling systems can be linked to improperly designed or installed duct systems.
 It is therefore highly important to the success of an installation that the duct system be properly
 designed and installed. Use flexible duct collars to minimize the transmission of vibration/noise into
 the conditioned space. Where return air duct is short, or where sound could potentially to be a
 problem, sound absorbing liner should be used inside the duct.
- Duct must be insulated where it runs through an unconditioned space during the cooling season.

 The use of a vapor barrier is recommended to prevent absorption of moisture from the surrounding air into the insulation.
- The supply air duct connection should be properly sized by use of a transition to match unit opening.
- All ducts should be suspended using flexible hangers and never fastened directly to the structure. This unit is not designed for nonducted (freeblow) applications.
- Duct work should be fabricated and installed in accordance with local and/or national codes.


↑ CAUTION -

A field-fabricated secondary drain pan, with a drain pipe to the outside of the building, is required in all installations over a finished living space or in any area that may be damaged by overflow from the main drain pan. In some localities, local codes may require a secondary drain pan for any horizontal installation.


Selection of installation direction

Di erent installation directions

The units can be installed in a vertical (down and up)and Horizontal(right and left) configuration.



Airflow direction of di erent installation directions



NOTICE

• Vertical up and horizontal left installation does not need to change the direction of evaporator.

Connecting the wire and pipes (pipes and drainage pipes)

Please follow these steps to perform **Vertical down** installation and **Horizontal right** installation:



Step 1

Open the upper cover.

Step 2

Open the cover of the electronic control box.

Step 3

Connect the wire according to the wiring diagram.

Step 4


Connect the pipes and install the drainage pipes.


Down flow and horizontal right instructions




NOTICE -

The unit may be installed in one of the upflow, downflow, horizontal left or horizontal right orientations.







Step 1

Remove the filter door, then take the filter o .

Step 2


Remove the upper cover assembly.

Step 3


Remove evaporator cover plate.

Indication of the position of each temperature sensor of the evaporator:


18-24K model



30-48K model



60K model



Step 5


Unplug temperature sensors T1, T2, T2A, T2B and electronic expansion valve (EEV) from the control board.

T1: Room temperature sensor

T2: Evaporator central sensor plug

T2A: Evaporator intput sensor plug

T2B: Evaporator output sensor plug




NOTE


T2A and T2B are only available for some models.

Step 6

Remove T1, T2, T2A, T2B, EEV sensor wire ties.




Take out the evaporator and drain pan and rotate 180° (when your equipment need to be vertical downed configuration).




Step 7

Adjust the mounting parts position according to the direction of equipment.




Step 8

Reinstall the evaporator and drain pan.



Step 9


Reinstall T1, T2, T2A, T2B sensor plugs and electronic expansion valve (EEV) and tie up the sensor wires.



NOTICE


The wire body needs to pass through the wire groove from the drain pan and be stuck on the hook of the drain pan.

The evaporator is assembled in place.




Step 11

Use cable ties to fix the room temperature sensor as shown in the figure.



Step 12

Reinstall evaporator cover plate.




Step 13

Connect the wire according to the wiring diagram.

Step 14

Reassenble the upper cover and Reinstall the filter, filter cover plate.



Step 15

Connect the pipes and install the drainage pipes.

A CAUTION FOR ALL PIPES INSTALLATION

- · Insulate all piping to prevent condensation, which could lead to water damage.
- The drainpipe is used to drain water away from the unit. If the drainpipe is bent or installed incorrectly, water may leak and cause a water-level switch malfunction.
- In HEAT mode, the outdoor unit will discharge water. Ensure that the drain hose is placed in an appropriate area to avoid water damage and icy conditions on walkways.
- DO NOT pull the drainpipe forcefully. This could disconnect it.

NOTICE

If installed above a finished living space, a secondary drain pan (as required by many building codes), must be installed under the entire unit and its condensate drain line must be routed to a location such that the user will see the condensate discharge.

NOTICE ON PURCHASING PIPES -

Installation requires pvc pipe or other suitable material per local and national codes, which can be obtained at your local hardware store or dealer.


WARNING


- After removal of drain pan plug(s), check drain hole(s) to verify that drain opening is fully open and free of any debris. Also check to make sure that no debris has fallen into the drain pan during installation that may plug up the drain opening. Seal around the exiting drain pipe, liquid and suction lines to prevent infiltration of humid air.
- On units of this type, where the blower "draws" rather than "blows" air through the coil, traps must be installed in the condensate drain lines (primary and auxiliary, if used). Traps prevent the blower from drawing air through the drain lines into the air supply.

Vertical Installations

These units operate with a negative pressure at the drain connections and a drain trap is required. The trap needs to be installed as close to the unit as possible. Make sure the top of the trap is below the connection to the drain pan to allow complete drainage of the pan.

Vertical discharge





NOTICE

Horizontal runs must also have an anti-siphon air vent(standpipe) install ahead of the horizontal run to eliminate air trapping.

NOTE ON DRAINPIPE INSTALLATION

- The Figure shows how to trap or plug all drains during vertical discharge.
- The Figure shows how to trap or plug all drains during right-hand discharge.
- The seal plug are supplied as accessories and should be screwed tightly only by hand.
- Incorrect installation could cause water to flow back into the unit and flood

A CAUTION

 The drainpipe outlet should be at least 5cm(1.9in) above the ground. If it touches the ground, the unit may become blocked and malfunction.

REFRIGERANT PIPING CONNECTION

WARNING -

All field piping must be completed by a licensed technician and must comply with the local and national regulations.

- When the air conditioner is installed in a small room, measures must be taken to prevent the refrigerant concentration in the room from exceeding the safety limit in the event of refrigerant leakage. If the refrigerant leaks and its concentration exceeds its proper limit, hazards due to lack of oxygen may result.
- When installing the refrigeration system, ensure that air, dust, moisture or foreign substances do not enter the refrigerant circuit. Contamination in the system may cause poor operating capacity, high pressure in the refrigeration cycle, explosion or injury.
- Ventilate the area immediately if there is refrigerant leakage during the installation. Leaked refrigerant gas is both toxic and may be flammable. Ensure there is no refrigerant leakage after completing the installation work.

Notes on pipe length and elevation

The maximum length and drop height based on models.(Unit:m/ft.)

Capacity (Btu/h)	MaxLen pipi		Maximu hei	
	ft.	m	ft.	m
18k	98.4	30	65.6	20
24k/30k	164	50	82	25
36k/48k/60k	213	65	98.4	30

Ensure that the length of the refrigerant pipe, the number of bends, and the drop height between the indoor and outdoor units meets the requirements shown in the table next to it:


Name	Shape		Quantity(PC)
Connecting pipe assembly	Liquid	6.35(1/4in)	
	side	9.52(3/8in)	Parts you must
	Gas	12.7(1/2in)	purchase separately. Consult the dealer
		16(5/8in)	about the proper
	side	19(3/4in)	pipe size of the unit you purchased.
		22(7/8in)	

⚠ CAUTION

Oil traps

If oil flows back into the outdoor unit's compressor, this might cause liquid compression or deterioration of oil return. Oil traps in the rising gas piping can prevent this.

An oil trap should be installed every 6m(20ft) of vertical suction line riser (<36000Btu/h unit). An oil trap should be installed every 10m(32.8ft) of vertical suction line riser (≥36000Btu/h unit).



Connection Instructions—Refrigerant Piping

↑ CAUTION -

• Insulate both the gas and liquid piping to prevent condensation.


Air Handler Unit Model			Adapter Required at Air Handler Unit (in.flare to braze)	Outdoor Model	Outdoo Connec (in.fla	tion	Adapter Required at Outdoor Unit(in.flare to flare or braze)
	Liquid	3/8	3/8 are→3/8braze		Liquid	3/8	3/8 are→3/8braze
18K/24K	Gas	3/4	3/4 are→3/4braze	18K/24K	Gas	5/8	5/8 are→3/4 are
	Ous	3/4	3/4 die 73/4blaze		Ods	3/0	5/8 are→3/4braze
24K/30K/	Liquid	3/8	3/8 are→3/8braze	24K(Hyper Heat)/30K/	Liquid	3/8	3/8 are→3/8braze
36K/48K	Gas	3/4	3/4 are→3/4braze	36K/48K	Gas	3/4	3/4 are→3/4braze
60K	Liquid	3/8	3/8 are→3/8braze	60K	Liquid	3/8	3/8 are→3/8braze
UUK	Gas	7/8	7/8 are→7/8braze	OUK	Gas	7/8	7/8 are→7/8braze

Step 1: Cut pipes

When preparing refrigerant pipes, take extra care to cut and flare them properly. This will ensure e cient operation and minimize the need for future maintenance.

Measure the distance between the

- indoor and outdoor units.
 Using a pipe cutter, cut the pipe a
- little longer than the measured distance.
- Make sure that the pipe is cut at a
- perfect 90° angle.




DO NOT DEFORM PIPE WHILE CUTTING

Be extra careful not to damage, kink, or deform the pipe while cutting. This will drastically reduce the heating performance.

Step 2: Remove burrs

Burrs can a ect the air-tight seal of refrigerant piping connection. They must be completely removed.


- Hold the pipe at a downward angle to prevent burrs from falling into the pipe.
- Using a reamer or deburring tool, remove all burrs from the cut section of the pipe.




Step 3: Flare pipe ends

Proper flaring is essential to achieve an airtight seal.

- After removing burrs from cut pipe, seal the ends with PVC tape to prevent foreign materials from entering the pipe.
- Sheath the pipe with insulating material.
- Place flare nuts on both ends of pipe. Make sure they are facing in the right direction, because you can't put them on or change their direction after flaring.



 Remove PVC tape from ends of pipe when ready to perform flaring work. • Clamp flare from on the end of the pipe. The end of the pipe must extend beyond the flare form.



- · Place flaring tool onto the form.
- Turn the handle of the flaring tool clockwise until the pipe is fully flared.



Pipe gauge	Tightening torque	Flare dimension(A) (Unit:mm/Inch)		Flare shape
gauge	torque	Min.	Max.	
Ø 6.35 (Ø 1/4")	18-20 N.m (180-200kgf.cm)	8.4/0.33	8.7/0.34	
Ø 9.52 (Ø3/8")	32-39 N.m (320-390kgf.cm)	13.2/0.52	13.5/0.53	90°±4
Ø 12.7 (Ø 1/2")	49-59 N.m (490-590kgf.cm)	16.2/0.64	16.5/0.65	A
Ø 16 (Ø 5/8")	57-71 N.m (570-710kgf.cm)	19.2/0.76	19.7/0.78	R0.4~0.8
Ø 19 (Ø 3/4")	67-101 N.m (670-1010kgf.cm)	23.2/0.91	23.7/0.93	
Ø 22 (Ø 7/8")	85-110 N.m (850-1100kgf.cm)	26.4/1.04	26.9/1.06	

 Remove the flaring tool and flare form, then inspect the end of the pipe for cracks and even flaring.


Step 4: Connect pipes

Connect the copper pipes to the indoor unit first, then connect it to the outdoor unit. You should first connect the low-pressure pipe, then the highpressure pipe.

- When connecting the flare nuts, apply a thin coat of refrigeration oil to the flared ends of the pipes.
- Align the center of the two pipes that you will connect.
- Tighten the flare nut snugly by hand.
- Using a wrench, grip the nut on the unit tubing.
- While firmly gripping the nut, use a torque wrench to tighten the flare nut according to the torque values in above table.

NOTICE

Use both a spanner and a torque wrench when connecting or disconnecting pipes to/from the unit.



↑ CAUTION


Ensure to wrap insulation around the piping. Direct contact with the bare piping may result in burns or frostbite.

Make sure the pipe is properly connected.
 Over tightening may damage the bell mouth and under tightening may lead to leakage.

NOTICE MINIMUM BEND RADIUS

Carefully bend the tubing in the middle according to the diagram below. **DO NOT** bend the tubing more than 90° or more than 3 times.

Use appropriate tool



min-radius 10cm(3.9")

 After connecting the copper pipes to the indoor unit, wrap the power cable, signal cable and the piping together with binding tape.

NOTICE

DO NOT intertwine or cross the signal cable with any other wiring.


- Thread this pipeline through the wall and connect it to the outdoor unit.
- Insulate all the piping, including the valves of the outdoor unit.
- Open the stop valves of the outdoor unit to start the flow of the refrigerant between the indoor and outdoor unit.


A CAUTION

Check to make sure there is no refrigerant leak after completing the installation work. If there is a refrigerant leak, ventilate the area immediately and evacuate the system (refer to the Air Evacuation section of this manual).

Air-Handler Air Conditioners Refrigerant Piping Connection


Correct Refrigerant piping Connecting installation methods





Braze connection

After the unit is installed, wrap the piping and brass fitting with foam tape.



INSTALLATION OF ELECTRIC **AUXILIARY HEAT MODULE**

(ONLY FOR HEAT FUNCTION MODELS)

NOTICE -

Installation must be performed by an licensed contractor. Please make necessary precaution when performing the installation operation.

Accessories

Name	Quantity	Name	Quantity
Manual	2	Silicone breaker cover	1
Foam gasket	1	Electric auxiliary heating wiring diagram	1
Screws	7	Circuit breaker label	1

Model size selection

For installations requiring supplemental heating, the optional Electric Auxiliary Heat Module is available in sizes from 3kW to 25kW to accommodate appropriate sizing given the specific heat load and electrical requirements of each installation. Please refer to the table below for selection of available sizes of each model, being sure to avoid improper matching.

MODEL (Btu/h)	3kW	5kW	8kW	10kW	15kW	20kW	25kW
18K	Υ	Υ	Υ	Υ	-	-	-
24K	-	Υ	Υ	Υ	Υ	-	-
30K	-	Υ	Υ	Υ	Υ	-	-
36K	-	Υ	Υ	Υ	Υ	Υ	-
48K	-	-	Υ	Υ	Υ	Υ	-
60K	-	-	-	Υ	Υ	Υ	Υ



NOTICE


Only use matched modules certified for use with model. Please refer to the Electric Auxiliary Heat Model specification for additional details to ensure proper selection and installation.

Preparations for Installation

Before installation, please confirm the electric auxiliary heat module and supplied accessories are complete and free of any damage. Do not attempt to install if damage is present.

Electric Auxiliary Heat Module installation and Wiring Operation






Open the upper cover.


Step 1

Step 2

Use tools to remove the knock-out holes of upper cover.




Remove the terminal block and power wires, loosen the screws, and remove the electric auxiliary heating cover.




Step 4

Install the electric auxiliary heating assembly the front, and note that the support assembly must lock into the support holes in the back of the cabint.



Step 5

Tighten the mounting screws.




Step 6

Wire according to the wiring nameplate. Apply the wiring diagram to the inside cover wiring is completed for future reference and maintenance.

Step 7

Install the upper cover, and the silicone breaker cover.



Step 8

After installing the electric auxiliary heat module, apply the circuit breaker label near the silicone breaker cover that was just applied.

CONFIRMATION OF INDOOR UNIT

■ NOTICE —

Electric auxiliary heating wiring diagram packed with the accessories. If branch circuit wire length exceeds 100 ft, consult NEC 210-19a to determine maximum wire length. Use 2% voltage drop.

After the electric heating wiring is connected, please confirm before power on:

- Check all wiring and ensure secure connection of all wiring.
- Ensure that wire size is properly selected per NEC or local codes.

Specifications	Number of circuit breakers	Number of relays	Number of power cord groups	Number of power cord grounding screws
3kW	1	1	2	2
5kW	1	1	2	2
8kW	1	2	2	2
10kW	1	2	2	2
15kw	2	3	3	3
20kW	2	4	3	3
25kW	3	5	4	4

Units without electrical heat

UNIT	IT VOITS-PHASE Rated MIN CKT AMPS -		BRANCH	CIRCUIT	
SIZE	VUITS-PHASE	current(A)	MIIN CRT AMPS	MIN WIRE SIZE AWG*	FUSE/CKT BKR AMPS
18K	208/230-1	2.0	2.5	14#	15.0
24K	208/230-1	3.0	4.0	14#	15.0
30K	208/230-1	3.5	4.5	14#	15.0
36K	208/230-1	4.0	5.0	14#	15.0
48K	208/230-1	6.0	7.5	14#	15.0
60K	208/230-1	7.0	9.0	14#	15.0

Use copper wire only to connect unit. If other than uncoated (non-plated) 75°C copper wire (solid wire for 10 AWG and smaller, stranded wire for larger than 10 AWG) is used consult applicable tables of the National Electric Code (ANSI/NFPA 70).




NOTICE

The specification may be di erent between di erent models ,please refer to indoor unit 's nameplate. Choose the cable type according to the local electrical codes and regulations. Please choose the right cable size according to the Minimum Circuit Ampacity indicated on the nameplate of the unit.

Auxilliary Heater Electrical Date

			CIR	CIRCUIT 1 208/230\	30V		CIRCUIT 2			CIRCUIT 2	
Heater Part No.	Heater KW	Internal Circuit Protection	Heater Amps	MCA (1) M	MOCP (2)	Heater Amps	MCA (1)	MCA (1) MOCP (2)	Heater Amps	MCA (1)	MOCP (2)
EAH-03B(UL)	3	Ckt Bkr	10.8/12.0	14.0/16.0	15.0/20.0	/	/	/	/	/	/
EAH-05B(UL)	5	Ckt Bkr	18.0/20.0	23.0/27.0	25.0/30.0	/	/	/	/	/	/
EAH-08B(UL)	_∞	Ckt Bkr	28.8/32.0	37.0/42.0	40.0/45.0	/	/	/	/	/	/
EAH-10B(UL)	10	Ckt Bkr	36.0/40.0	46.0/53.0	20.0/60.0	/	/	/	/	/	/
EAH-15B(UL)	15	Ckt Bkr	18.0/20.0	23.0/27.0	25.0/30.0	36.0/40.0	46.0/53.0	50.0/60.0	/	/	/
EAH-20B(UL)	20	Ckt Bkr	36.0/40	46.0/53.0	50.0/60.0	36.0/40.0	46.0/53.0	50.0/60.0	/	_	/
EAH-25B(UL)	25	Ckt Bkr	18.0/20.0	23.0/27.0	25.0/30.0	36.0/40.0	46.0/53.0	50.0/60.0	36.0/40.0	46.0/53.0	50.0/60.0

Electric auxiliary heating wiring diagram



optional, The wiring type of the actual unit shall prevail.

Please attach the nameplate to the cover of the electric control box. All the round holes located on the plate represent numbers. Please refer to the Installation Manual for details.

Round hole number	Relay number	Round hole number	Circuit breaker number
¢	RELAY1	e	CB1
0.0			
000			
0000			
00000			


NOTE3: TO BE WIRED IN ACCORDANCE WITH NEC AND LOCAL CODES. NOTE4: POWER A,B,C,D ARE DIFFERENT POWERS.

The wiring mode of power supply A shall be based on the type of original wiring terminal of AHU; for type A, S position must be connected to the ourdoor S; for type B, S position shall not be connected.



8KW/10KW HEAT KIT

:thermal cut-out -thermal link, self-resetting



NOTE1:

This symbol indicates the element is optional, The wiring type of the actual unit shall prevail.

NOTE2:

NOTE2.
Please attach the nameplate to the cover of the electric control box. All the round holes located on the plate represent numbers. Please refer to the Installation Manual for details.

lound hole number	Relay number	Round hole number	Circuit breaker number
0	RELAY1	0	CB1
ee .	RELAY 2		
000			
0000			
00000			

NOTE3: TO BE WIRED IN ACCORDANCE WITH NEC AND LOCAL CODES.


NOTE4: POWER A,B,C,D ARE DIFFERENT POWERS.

The wiring mode of power supply A shall be based on the type of original wiring terminal of AHU; for type A, S position must be connected to the ourdoor S; for type B, S position shall not be connected. be connected.



15KW HEAT KIT

 thermal cut-out :thermal link, self-resetting



This symbol indicates the element is optional, The wiring type of the actualunit shall prevail.

Please attach the nameplate to the cover of the electric control box. All the round holes located on the plate represent numbers. Please refer to the Installation Manual for details.

l	Round hole number	Relay number	Round hole number	Circuit breaker number
	e	RELAY1	0	CB1
l	00	RELAY 2	ee	CB2
l	000	RELAY 4		
l	0000			
l	00000			

NOTE3: TO BE WIRED IN ACCORDANCE WITH NEC AND LOCAL CODES.


NOTE4: POWER A,B,C,D ARE DIFFERENT POWERS.

The wiring mode of power supply A shall be based on the type of original wiring terminal of AHU; for type A, S position must be connected to the ourdoor S; for type B, S position shall not be connected.



20KW HEAT KIT

:thermal cut-out = :thermal link, self-resetting



This symbol indicates the element is optional, The wiring type of the actual unit shall prevail.

NOTE2: Please attach the nameplate to the cover of the electric control box. All the round holes located on the plate represent numbers. Please refer to the Installation Manual for details.

Round hole number	Relay number	Round hole number	Circuit breaker numbe
e	RELAY1	0	CB1
00	RELAY 2	00	CB2
900	RELAY 3		
0000	RELAY 4		
00000			


NOTE3: TO BE WIRED IN ACCORDANCE WITH NEC AND LOCAL CODES

NOTE4: POWER A,B,C,D ARE DIFFERENT POWERS.

The wiring mode of power supply A shall be based on the type of original wiring terminal of AHU; for type A, S position must be connected to the ourdoor S; for type B, S position shall not be connected.



Electric auxiliary heating wiring diagram



TYPE A

TYPE B

00000

RELAY 5

OUTDOOR UNIT INSTALLATION




Install the unit by following local switchs and regulations, there may be dier slightly between dierent regions.

Select the installation location of outdoor units

Before installing the outdoor unit, you must choose an appropriate location. The following are standards that will help you choose an appropriate location for the unit.

Proper installation locations meet the following standards:








Meets all spatial requirements shown in Installation Space Requirements above.

Firm and solid—the location can support the unit and will not vibrate.

Noise from the unit will not disturb other people.







The outdoor unit must be installed on risers of at least 15cm(6in) in height or per local code to get unit above local mean snow fall.

Good air circulation and ventilation.

Where snowfall is anticipated, take appropriate measures to prevent ice buildup and coil damage.

DO NOT install unit in the following locations:

- Near an obstacle that will block air inlets and outlets.
- In a location that is exposed to large amounts of dust.
- Near animals or plants that will be harmed by hot air discharge.
- Near any source of combustible gas

Near a public street, crowded areas, or where noise from the unit will disturb others.

⚠ CAUTION: —


SPECIAL CONSIDERATIONS FOR EXTREME WEATHER

If the unit is exposed to heavy wind:


Install unit so that air outlet fan is at a 90° angle to the direction of the wind. If needed, build a barrier in front of the unit to protect it from extremely heavy winds. See Figures below.

If the unit is frequently exposed to heavy rain or snow:

Build a shelter above the unit to protect it from the rain or snow. Be careful not to obstruct air flow around the unit.



90° angle to the direction of the wind




Build a wind Ba e to protect the unit




Build a shelter to protect the unit

Install drain fitting(Heat pump unit only)



Step 1:

Find out the base pan hole of outdoor unit.



Step 2:

- Fit the rubber seal on the end of the drain fitting that will connect to the outdoor unit.
- Insert the drain fitting into the hole in the base pan of the unit. The drain fitting will click in place.
- Connect a drain hose extension (not included) to the drain fitting to redirect water from the unit during heating mode.


IN COLD CLIMATES

In cold climates, make sure that the drain hose is as vertical as possible to ensure swift water drainage. If water drains too slowly, it can freeze in the hose and flood the unit.

Anchor outdoor unit


The outdoor unit can be anchored to the ground or to a wall-mounted bracket with bolt(M10). Prepare the installation base of the unit according to the dimensions below.

Outdoor Unit Types and Specifications



	Outdoor Unit Dimensions						Mounting	g Dimen	sions
\	N		Н		D		A		В
mm	inch	mm	inch	mm	inch	mm	inch	mm	inch
805	31-11/16	554	21-13/16	330	13	511	20-1/8	317	12-1/2
890	35	673	26-1/2	342	13-15/32	663	26-1/8	354	13-15/16
946	37-1/4	810	31-29/32	410	16-5/32	673	26-1/2	403	15-7/8
952	37-1/2	1333	52-1/2	415	16-11/32	634	24-35/36	404	15-29/32

(unit: mm/inch)



If you will install the unit on the ground or on a concrete mounting platform, DO THE FOLLOWING:

- Mark the positions for four expansion bolts based on dimensions chart.
- Pre-drill holes for expansion bolts.
- Place a nut on the end of each expansion bolt.
- Hammer expansion bolts into the pre-drilled holes.
- Remove the nuts from expansion bolts, and place outdoor unit on bolts.
- Put washer on each expansion bolt, then replace the nuts.
- Using a wrench, tighten each nut until snug.

A WARNING

WHEN DRILLING INTO CONCRETE, EYE PROTECTION IS RECOMMENDED AT ALL TIMES.

If you will install the unit on a wall-mounted bracket, DO THE FOLLOWING:

- Mark the position of bracket holes based on dimensions chart.
- Pre-drill the holes for the expansion bolts.
- Place a washer and nut on the end of each expansion bolt.
- Thread expansion bolts through holes in mounting brackets, put mounting brackets in position, and hammer expansion bolts into the wall.
- Check that the mounting brackets are level.
- Carefully lift unit and place its mounting feet on brackets.
- Bolt the unit firmly to the brackets.
- If allowed, install the unit with rubber isolator pads o reduce vibrations and noise.

↑ CAUTION

Make sure that the wall is made of solid brick, concrete, or of similarly strong material. The wall must be able to support at least four times the weight of the unit.

WIRING PRECAUTIONS

WARNING -

BEFORE PERFORMING ANY ELECTRICAL WORK, READ THESE WARNINGS.


- All wiring must comply with local and national electrical codes, regulations and must be installed by a licensed electrician.
- All electrical connections must be made according to the Electrical Connection Diagramlocated on the panels of the indoor and outdoor units.
- If there is a serious safety issue with the power supply, stop work immediately. Explain your reasoning to the client, and refuse to install the unit until the safety issue is properly resolved.
- Power voltage should be within 90-110% of rated voltage. Insu cient power supply can cause malfunction, electrical shock, or fire.
- Installation of an external surge suppressor at the outdoor disconnect is recommended.
- If connecting power to fixed wiring, a switch or circult breaker that disconnects all poles and has a contact separation of at least 1/8in (3mm) must be incorporated in the fixed wiring. The qualified technician must use an approved circuit breaker or switch.
- Only connect the unit to an individual branch circuit. Do not connect another appliance to that Circuit.
- Make sure to properly ground the air conditioner.
- Every wire must be firmly connected. Loose wiring can cause the terminal to overheat, resulting in product malfunction and possible fire.

- Do not let wires touch or rest against refrigerant tubing, the compressor, or any moving parts within the unit.
- To avoid getting an electric shock, never touch the electrical components soon after the power supply has been turned o . After turning o the power, always wait 10 minutes or more before you touch the electrical components.
- Make sure that you do not cross your electrical wiring with your signal wiring.
 This may cause distortion, interference or
- possibly damage to circuit boards.
- No other equipment should be connected to the same power circuit.
- Connect the outdoor wires before connecting the indoor wires.

WARNING

BEFORE PERFORMING ANY ELECTRICAL OR WIRING WORK, TURN OFF THE MAIN POWER TO THE SYSTEM.

Wiring overview



NOTICE

The diagrams are for explanation purpose only. Your machine may be slightly dierent. The acyual diagram shall prevail.

OUTDOOR UNIT WIRING

♠ WARNING -

Before performing any electrical or wiring work, turn o the main power to the system.

Step 1: Prepare the cable for connection.


- 1. You must first choose the right cable size.
- 2. Using wire strippers, strip the rubber jacketfrom both ends of the signal cable to reveal approximately 15cm (5.9") of wire.
- 3. Strip the insulation from the ends.
- 4. Stranded wire requires u-lugs or ring terminals to be crimped onto the ends of the wire.

NOTICE

- When connecting the wires, strictly follow the wiring diagram found inside the electrical box cover.
- Choose the cable type according to the local electrical switchs and regulations.
- · Please choose the right cable size according to the Minimum Circuit Ampacity indicated on the nameplate of the unit.


Step 2: Remove the electric cover.


Remove the electric cover of the outdoor unit. If there is no cover on the outdoor unit, take o the bolts from the maintenance board and remove the protection board.



Step 3: Connect the u-lugs to the terminals

Match the wire colors/labels with the labels on the terminal block. Firmly screw the u-lug of each wire to its corresponding terminal.






Outdoor Unit B

- 4. Clamp down the cable with the cable clamp.
- 5. Insulate unused wires with electrical tape. Keep them away from any electrical or metal parts.
- 6. Reinstall the cover of the electric control box.

In North America

- 1. Remove the wire cover from the unit by loosening the 3 screws.
- 2. Remove caps on the conduit panel.
- 3. Mount the conduit tubes(not included) on the caonduit panel.
- 4. Properly connect both the power supply and low voltage lines to the corresponding terminals on the terminal block.
- 5. Ground the unit in accordance with local switchs.
- 6. Be sure to size each wire allowing several inches longer than the required length for wiring.





WARNING

ISOLATE THE POWER SUPPLY LEADS AND COMMUNICATION LEADS BY THE STRAIN RELIF AND KEEP POWER SUPPLY LEADS AWAY FROM COMMUNICATION LEADS.

INDOOR UNIT WIRING

↑ CAUTION -

- While connecting the wires, please strictly follow the wiring diagram.
- The refrigerant circuit can become very hot. Keep the interconnection cable away from the copper tube.

Step 1: Prepare the cable for connection.


- 1. Using wire strippers, strip the insulating jacket from both ends of the signal cable to reveal about 15cm (5.9") of the wire.
- 2. Strip the insulation from the ends of the wires.

Step 2: Open the front panel of the indoor unit.

Using a screwdriver, remove the cover of the electric control box on your indoor unit.

Step 3: Connect the wires to the terminals.

- 1. Thread the power cable and the signal cable through the wire outlet
- 2. Match the wire colors/labels with the labels on the terminal block. Firmly screw the wires of each wire to its corresponding terminal. Refer to the Serial Number and Wiring Diagram located on the cover of the electric control box.



WARNING

ISOLATE THE POWER SUPPLY LEADS AND COMMUNICATION LEADS BY THE STRAIN RELIF AND KEEP POWER SUPPLY LEADS AWAY FROM COMMUNICATION LEADS.

- 3. Clamp down the cable with the cable clamp. The cable must not be loose or pull on the u-lugs.
- 4. Reattach the electric box cover.
- 5. Clamp down the cable with the cable clamp. The cable must not be loose or pull on the u-lugs.
- 6. Reattach the electric box cover

CAUTION

- While connecting the wires, please strictly follow the wiring diagram.
- The refrigerant circuit can become very hot. Keep the interconnection cable away from the copper tube.

SPECIFIC WIRING METHODS




WARNING -

Please refer to the wiring nameplate for the wiring method. Do not connect the power cord to the communication line, as this may damage the system.


Connection method A:

Refer to the wiring method of internal and external machine communication and wired controller as follows:



Connection method B:

To use a 24V thermostat, you need to refer to the following wiring:




When using a 24v thermostat, please refer to the non-communicating wiring diagrams that follow:

Connection method C:


The following wiring diagram are suitable for the AHU and ODU with 24V thermostat.

Non-communication scheme wiring reference


• Wiring for 4H and 2C thermostat




· Wiring for 3H and 1C thermostat




· Wiring for 3H and 2C thermostat




• Wiring for 3H and 2C thermostat



• Wiring for 2H and 2C thermostat




· Wiring for 2H and 1C thermostat




shorted for single stage Aux heat operation. Turn o to separate stages.


• Wiring for 1H and 1C thermostat



• Wiring for 1H and 1C thermostat




Optional function wiring:




Condensate overflow switch:

The unit will accommodate a remote condensate overflow switch. To enable, remove jumper J1, and connect the installer provided condensate overflow device to CN5 per below. When an overflow condition is present, the device should open connection signaling the unit to turn o the system.




The fault warning:



Alarm output:


An alarm output (CN33) can be utilized if actions are required when a fault is present. This is a passive outlet port, so you will need to input a voltage signal. The relay is normally-open for normal operation, and closed when a fault condition is active.

Humidifier control:



To connect a humidifier, utilize the passive signal "WORK" output (CN23) port as well as the G and C wires on the controller, and wire the humidistat and humidifier per above wiring diagram. When the fan is running, the CN23 relay will be closed, which will allow power to the humidifier when the humidistat is below humidity setpoint. If the thermostat or zone controller has an HUM interface, connect the humidifier directly to the HUM and C ports.

Dehumidification control wiring



Dehumidification control requires external Humidistat at DH and R. Set S4-2 as OFF. When the humidity rises and exceeds the set value of the Humidistat, the 24V signal of DH changes to OV, the cooling system starts the dehumidification operation, and the air volume drops to 80% of the nominal cooling air volume.

UV, fresh air or ion generator wiring



24V control signal or 208/230V power supply

The WORK port is linked with the fan. When the fan is running, the relay is closed; if an active 24V signal is required, it can be directly connected to the G and C ports.

Control logic

Indoor unit connector


Connector	Purpose
R	24V Power Connection
C	Common
G	Fan Control
Y1	Low Cooling
Y/Y2	High Cooling
В	Heating Reversing Valve
W	Heating control
W1	Stage 1 Electric Heating
W2	Stage 2 Electric Heating
E/AUX	Emergency Heating
DH/DS/BK	Dehumidification/Zoning control
L	System Fault Signal

Outdoor unit connector

Connector	Purpose
R	24V Power Connection
C	Common
Y1	Low Cooling
Y2	High Cooling
В	Heating Reversing Valve
W	Heating control
D	Defrost control
L	System Fault Signal


LED display

The control displays unit status as well as any active fault codes on the LED display. If the unit is functioning normally, the LED will display current temperature setpoint. When a fault code is active, the display will flash quickly the active fault code. Please refer to the fault code table located in the troubleshooting section of the manual for detailed fault code information.



Function DIP switch settings:

The 24V thermostat mode needs to refer to the following settings:



Function combination table of SW1-1 and SW1-4:


SW1	Control type	Stand alone or full system
ON 1 2 3 4	Free match	Free match
ON 1 2 3 4	Wired controller	Full system
ON 1 2 3 4	24V Thermostat	Full system
ON 1 2 3 4	24V Thermostat	Stand alone

Indoor unit dial code

No.	Dial Code	Control Scenario	Function	ON	OFF	Note	
1	SW1-2	1,2	Anti-cold blow protection option	NO	[Default] YES		
2	SW1-3	1,2,3	Single cooling / heating and and cooling options	Cooling	[Default] Cooling & Heating		
3	SW2-1	1	Compressor Running (demand working with heat pump+ Bectric heat)	Compressor slower speed	[Default] Faster Compressor		
4	SW2-1	2	Temperature di erential to activate first stage auxiliary heat(the GAPof T1 and Ts),Wire controller demand with heat pump+Bectric heat working together	2°F (1°C)	[Default] 4 °F (2°C)	Only a ects compressor and W1	
5	SW2-2	2	⊟ectric heat on delay	YES	[Default]NO		
6	SW2-3	2	Bectric auxiliary heating delay to start time	30 minutes	[Default] 15 minutes	Based on SW2-2 is ON	
7	SW2-4	2	Compressor/Auxiliary heat outdoor ambient lockout	The compressor will not operate if the outdoor temperature is lower than the temperature represented by S3	[Default] The heater will not operate if the outdoor temperature is greater than the temperature represented by S3	SW2-4 and S3 need to working together	
8	Rotary Switch S3	2	Set outdoor temperature Limitation (for auxiliary heating or compressor)	turned on, the dial range is 1 thr	0 means that the temperature protection is not turned on, the dial range is 1 through F, 1 equals -4°F and it increased up to 46°F based on table "A"		
9	SW3-1	1	Maximum continuous runtime allowed before system automatically stages up capacity to satisfy set point. This adds 1 to 5°F to the user set point in the calculated control point to increase capacity and satisfy user set point	30 minutes	[Default] 90 minutes		
10	SW3-2	1	Cooling and heating Y/Y2 temperature di erential adjustment.	Compressor slower speed	[Default] Faster Compressor	Only a ects compressor	
11	SW3-3	1	Compressor Running (demand working with heat pump+ Electric heat)	Compressor slower speed	[Default] Faster Compressor	Only a ects compressor and W2	
12	SW3-3	2	Temperature di erential to activate second stage auxiliary heating(the GAP of T1 and Ts)Wire controller demand with heat pump+Bectric heat working together	4°F (2°C)	[Default] 6 °F (3°C)		
13	SW3-4	1,3	Fan speed of cooling mode when 24V Thermostat is applied for.	Turbo	High		
14	S W4	1,2,3	Bectric heat nominal CFM adjustment	Available settings are 000/001/010/011. Each digit corresponds an indiviual swith position. For example [SW4-1 OFF, SW4-2 ON, SW4-3 OFF] = 010 See table 11 for the corresponding CFM adjustment			
15	S4-1	1,3	Default ON	[Default] For single stage supplemental heat, W1 and W2 are connected	For dual stage supplemental heat, W1 and W2 are controlled independently.		
16	S4-2	1,3	DH function selection	[Default] Dehumidi fication control not available	Dehumidification feature is enabled through thermostat		

NOTICE: The SW4 DIP switch is only for Certified service technicians to debug and use, please do not touch it.

	24V Tstat, S1+S2	1
Control Scenario	Wired Controller S1+S2	2
	Full 24V	3



ಽಽ	೮३ (°F)	ಿC)
0	OFF	OFF
1	-4	-20
2	-0	-18
3	3	-16
4	7	-14
5	10	-12
6	14	-10
7	18	-8
8	21	-6
9	25	-4
Α	28	-2
В	32	0
С	36	2
D	39	4
E	43	6
F	46	8

Outdoor unit DIP Switch setting

NO.	Dial code	Features	ON	OFF
1	SW-1	Metering device location	Outdoor throttling (normally closed single-way solenoid valve is not powered on)	Indoor throttling (normally closed single-way solenoid valve store)
2	SW-2	Communication dial code	24V communication scheme	485 communication scheme
3	SW-3	Strong cold and strong heat function	The cooling/heating target pressure compensation value is valid	The cooling/heating target pressure compensation value is invalid
4	SW-4	Function to be defined		

Address DIP switch:

Address dialing S1+S2: When the user uses the centralized controller, the address dialing is required.

Network address: The address silkscreen is NET address, which is composed of a 16-bit address rotary code S2 plus a two-digit DIP switch S1 [Set during engineering installation, no network function does not need to be set]
When S2 is 00 (the dialing code is not connected), the network address value is the value of S2:

the network address value is the value of S2; When S2 is 10 (corresponding to the switch of the hardware connected to the 10K resistor), the network address value is S2 plus 32; Determined by dial code S2 1-10K 2-5.1K When S2 is O1 (corresponding to the dial code of

the 5.1K resistor connected to the hardware is turned on), the network address value is the value of S2 plus 16;

When S2 is 11 (all dialing codes are on), the network address value is the value of S2 plus 48.

Determined by dial code S2 1-10K 2-5.1K

Dial code selection	Website address
ON 1 2	S2 + 48
ON 1 2	S2 + 32
ON 1 2	S2 + 16
ON 1 2	S2



NOTICE

The SW4 DIP switch is only for Certified service technicians to debug and use, please do not touch it.

Air volume table

							. "		
	External Static Pressure Range	Fan speed	Bectric heater kit	24V thermostat		Wired controller		Air ow	
Capacity				DIPSwitch	24V terminal engaged	DIP Switch	Mode	volume (CFM)	
		Cooling Turbo	_	SW3-4=ON	Y2/Y	_	Cool	618	
18K (1.5 Ton)		Cooling High	_	SW3-4=OFF	Y2/Y	_	Cool	576	
		Cooling Medium	_	_	Y1	_	Cool	529	
		Cooling Low	_	_	_	_	Cool	488	
		Heat Pump Turbo	_	_	_	_	Heat	565	
		Heat Pump High	_	_	B+Y2/Y, W	_	Heat	541	
		Heat Pump Medium	_	_	Y1	_	Heat	435	
		Heat Pump Low	_	_	_	_	Heat	400	
	18K (1.5 Ton)	0 - 0.80 in. w.g.	Bectric heater kit 0(Default)	10KW	SW4-1=OFF SW4-2=OFF SW4-3=OFF	W1, W2, AUX	SW4-1=OFF SW4-2=OFF SW4-3=OFF	Heat + AUX, AUX	653
		Bectric heater kit 1	10KW, 8KW	SW4-1=OFF SW4-2=OFF SW4-3=ON	W1, W2, AUX	SW4-1=OFF SW4-2=OFF SW4-3=ON	Heat + AUX, AUX	624	
		Bectric heater kit 2	8KW	SW4-1=OFF SW4-2=ON SW4-3=OFF	W1, W2, AUX	SW4-1=OFF SW4-2=ON SW4-3=OFF	Heat + AUX, AUX	594	
		Bectric heater kit 3	5KW, 3KW	SW4-1=OFF SW4-2=ON SW4-3=ON	W1, W2, AUX	SW4-1=OFF SW4-2=ON SW4-3=ON	Heat + AUX, AUX	565	
		Cooling Turbo	_	SW3-4=ON	Y2/Y	_	Cool	824	
		Cooling High	_	SW3-4=OFF	Y2/Y	_	Cool	759	
			Cooling Medium	_	_	Y1	_	Cool	694
			Cooling Low	_	_	_	_	Cool	629
		Heat Pump Turbo	_	_	_	_	Heat	788	
		Heat Pump High	_	_	B+Y2/Y, W	_	Heat	753	
		Heat Pump Medium	_	_	Y1	_	Heat	641	
		Heat Pump Low	_	_	_	_	Heat	524	
24K (2 Ton)	0 - 0.80 in. w.g.	Bectric heater kit 0(Default)	15KW	SW4-1=OFF SW4-2=OFF SW4-3=OFF	W1, W2, AUX	SW4-1=OFF SW4-2=OFF SW4-3=OFF	Heat + AUX, AUX	871	
		Bectric heater kit 1	15KW, 10KW	SW4-1=OFF SW4-2=OFF SW4-3=ON	W1, W2, AUX	SW4-1=OFF SW4-2=OFF SW4-3=ON	Heat + AUX, AUX	841	
		Bectric heater kit 2	10KW, 8KW	SW4-1=OFF SW4-2=ON SW4-3=OFF	W1, W2, AUX	SW4-1=OFF SW4-2=ON SW4-3=OFF	Heat + AUX, AUX	818	
		Bectric heater kit 3	5KW	SW4-1=OFF SW4-2=ON SW4-3=ON	W1, W2, AUX	SW4-1=OFF SW4-2=ON SW4-3=ON	Heat + AUX, AUX	788	
		Cooling Turbo	_	SW3-4=ON	Y2/Y	_	Cool	988	
		Cooling High	_	SW3-4=OFF	Y2/Y		Cool	894	
		Cooling Medium	_	_	Y1	_	Cool	806	
		Cooling Low	_		_		Cool	712	
		Heat Pump Turbo	_	_	_	_	Heat	918	
		Heat Pump High	_	_	B+Y2/Y, W	_	Heat	876	
		Heat Pump Medium	_	_	Y1	_	Heat	665	
		Heat Pump Low	_	_	_	_	Heat	453	
30K (2.5 Ton)	0 - 0.80 in. w.g.	Bectric heater kit 0(Default)	15KW	SW4-1=OFF SW4-2=OFF SW4-3=OFF	W1, W2, AUX	SW4-1=OFF SW4-2=OFF SW4-3=OFF	Heat + AUX, AUX	1088	
		Bectric heater kit 1	15KW, 10KW	SW4-1=OFF SW4-2=OFF SW4-3=ON	W1, W2, AUX	SW4-1=OFF SW4-2=OFF SW4-3=ON	Heat + AUX, AUX	1029	
		Bectric heater kit 2	10KW, 8KW	SW4-1=OFF SW4-2=ON SW4-3=OFF	W1, W2, AUX	SW4-1=OFF SW4-2=ON SW4-3=OFF	Heat + AUX, AUX	976	
		Bectric heater kit 3	5KW	SW4-1=OFF SW4-2=ON SW4-3=ON	W1, W2, AUX	SW4-1=OFF SW4-2=ON SW4-3=ON	Heat + AUX, AUX	918	

Air volume table

					Ave.		. "		
	External Static Pressure Range			24V thermostat		Wired	controller	Air fbw	
Capacity		Fan Speed	Electric heater kit	DIP Switch	24V terminal engaged	DIP Switch	Mode	volume (CFM)	
		Cooling Turbo	_	SW3-4=ON	Y2/Y	_	Cool	1188	
		Cooling High	_	SW3-4=OFF	Y2/Y	_	Cool	1082	
		Cooling Medium	_	_	Y1	_	Cool	971	
		Cooling Low	_	_	_	_	Cool	865	
36K (3 Ton)		Heat Pump Turbo	_	_	_	_	Heat	1112	
		Heat Pump High	_	_	B+Y2/Y, W	_	Heat	1059	
		Heat Pump Medium	_	_	Y1	_	Heat	794	
		Heat Pump Low	_	_	_	_	Heat	582	
	0 - 0.80 in. w.g.	Bectric heater kit 0(Default)	20KW	SW4-1=OFF SW4-2=OFF SW4-3=OFF	W1, W2, AUX	SW4-1=OFF SW4-2=OFF SW4-3=OFF	Heat + AUX, AUX	1306	
		⊟ectric heater kit 1	15KW	SW4-1=OFF SW4-2=OFF SW4-3=ON	W1, W2, AUX	SW4-1=OFF SW4-2=OFF SW4-3=ON	Heat + AUX, AUX	1241	
		Bectric heater kit 2	10KW, 8KW	SW4-1=OFF SW4-2=ON SW4-3=OFF	W1, W2, AUX	SW4-1=OFF SW4-2=ON SW4-3=OFF	Heat + AUX, AUX	1176	
		Bectric heater kit 3	5KW, 8KW	SW4-1=OFF SW4-2=ON SW4-3=ON	W1, W2, AUX	SW4-1=OFF SW4-2=ON SW4-3=ON	Heat + AUX, AUX	1112	
		Cooling Turbo	_	SW3-4=ON	Y2/Y	_	Cool	1471	
			Cooling High	_	SW3-4=OFF	Y2/Y	_	Cool	1282
				Cooling Medium	_	_	Y1	_	Cool
		Cooling Low	_	_	_	_	Cool	906	
		Heat Pump Turbo	_	_	_	_	Heat	1471	
		Heat Pump High	_	_	B+Y2/Y, W	_	Heat	1306	
		Heat Pump Medium	_	_	Y1	_	Heat	1141	
		Heat Pump Low	_	_	_	_	Heat	976	
48K (4 Ton)	0 - 0.80 in. w.g.	Bectric heater kit 0(Default)	20KW	SW4-1=OFF SW4-2=OFF SW4-3=OFF	W1, W2, AUX	SW4-1=OFF SW4-2=OFF SW4-3=OFF	Heat + AUX, AUX	1741	
		Bectric heater kit 1	15KW	SW4-1=OFF SW4-2=OFF SW4-3=ON	W1, W2, AUX	SW4-1=OFF SW4-2=OFF SW4-3=ON	Heat + AUX, AUX	1653	
		Electric heater kit 2	10KW, 8KW	SW4-1=OFF SW4-2=ON SW4-3=OFF	W1, W2, AUX	SW4-1=OFF SW4-2=ON SW4-3=OFF	Heat + AUX, AUX	1559	
		Electric heater kit 3	8KW	SW4-1=OFF SW4-2=ON SW4-3=ON	W1, W2, AUX	SW4-1=OFF SW4-2=ON SW4-3=ON	Heat + AUX, AUX	1471	
		Cooling Turbo	_	SW3-4=ON	Y2/Y	_	Cool	1806	
		Cooling High	_	SW3-4=OFF	Y2/Y	_	Cool	1582	
		Cooling Medium	_	_	Y1	_	Cool	1359	
		Cooling Low	_	_	_	_	Cool	1135	
		Heat Pump Turbo	_	_	_	_	Heat	1659	
		Heat Pump High	_	_	B+Y2/Y, W	_	Heat	1582	
		Heat Pump Medium	_	_	Y1	_	Heat	1247	
		Heat Pump Low					Heat	976	
60K (5 Ton)	0 - 0.80 in. w.g.	Electric heater kit 0(Default)	25KW	SW4-1=OFF SW4-2=OFF SW4-3=OFF	W1, W2, AUX	SW4-1=OFF SW4-2=OFF SW4-3=OFF	Heat + AUX, AUX	2171	
		Electric heater kit 1	15KW, 20KW	SW4-1=OFF SW4-2=OFF SW4-3=ON	W1, W2, AUX	SW4-1=OFF SW4-2=OFF SW4-3=ON	Heat + AUX, AUX	2029	
		Electric heater kit 2	10KW, 15KW	SW4-1=OFF SW4-2=ON SW4-3=OFF	W1, W2, AUX	SW4-1=OFF SW4-2=ON SW4-3=OFF	Heat + AUX, AUX	1894	
		Bectric heater kit 3	10KW	SW4-1=OFF SW4-2=ON SW4-3=ON	W1, W2, AUX	SW4-1=OFF SW4-2=ON SW4-3=ON	Heat + AUX, AUX	1753	



NOTICE

The constant airflow volume motor is applied .So the airflow volume is constant at all ESP within stated range.

POWER SPECIFICATIONS

Cooling and Heating power specifications

	MODEL(Btu/h)		18K	24K	30K	
POWER		PHASE			1 Phase		
	(outdoor)	FREQUENCY AND VOLT			208/230V,60Hz	<u>z</u>	
INPUT CIRCUIT FUSE		OUTDOOR UNIT(A) MC	CA OCP	Std Hyper HT 16 / 16 20 / 20	Std Hyper HT 19 / 20 30 / 35	Std Hyper HT 20 / 23 35 / 35	
	OLITDOOD LINIT	LINE QUANTITY		2+Ground			
LINES	OUTDOOR UNIT POWER LINE	LINE DIAMETER(AWG)		STD 12 HH 12	STD 12 HH 12	STD 12 HH 10	
	OUTDOOR-INDOOR	LINE QUANTITY			2		
GAUGE	SIGNAL LINE	LINE DIAMETER(AWG)			20		
	THERMOSTAT	LINE QUANTITY					
	SIGNAL LINE	LINE DIAMETER(AWG)			18		

	MODEL(Btu/h)	36K	48K	60K			
	POWER	PHASE	PHASE		1 Phase			
	(outdoor)	FREQUENCY AND VO	LT		208/230V,60Hz			
IN	NPUT CIRCUIT FUSE	OUTDOOR UNIT(A)	MCA MOCP	Std Hyper HT 24 / 41 40 / 50	Std Hyper HT 34 / 42 50 / 50	Std Hyper HT 34 / NA 60 / NA		
		LINE QUANTITY		2+Ground				
LINES	OUTDOOR UNIT POWER LINE	LINE DIAMETER(AWG))	STD 10 HH 8	STD 8 HH 6	STD 8 HH NA		
	OUTDOOR-INDOOR	LINE QUANTITY		2				
GAUGE	SIGNAL LINE LINE DIAMETER(AWG))	20				
	THERMOSTAT	LINE QUANTITY						
	SIGNAL LINE	LINE DIAMETER(AWG))	18				

NOTICE

Line Diameter Sizing per NFPA 70 (2020), Table 310.15 (B) (16) Based on type NM-B Romex wire. Other sizing options are possible. Consult NFPA 70 or Licensed Electrician for alternate sizing.

AIR EVACUATION



NOTICE -

When opening valve stems, turn the hexagonal wrench until it hits against the stopper. Do not try to force the valve to open further.

Preparations and precautions

Air and foreign matter in the refrigerant circuit can cause abnormal rises in pressure, which can damage the air conditioner, reduce its e ciency, and cause injury. Use a vacuum pump and manifold gauge to evacuate the refrigerant circuit, removing any non-condensable gas and moisture from the system. Evacuation should be performed upon initial installation and when unit is relocated.


BEFORE PERFORMING EVACUATION

- Check to make sure the connective pipes between the indoor and outdoor units are connected properly.
- Check to make sure all wiring is connected properly.


Evacuation Instructions

- Connect the charge hose of the manifold gauge to service port on the outdoor unit's low pressure valve.
- 2. Connect another charge hose from the manifold gauge to the vacuum pump.
- 3. Open the Low Pressure side of the manifold gauge. Keep the High Pressure side closed.
- 4. Turn on the vacuum pump to evacuate the system.
- 5. Run the vacuum for at least 15 minutes, or until the Compound Meter reads -750 Microns(-10⁵Pa).

Outdoor unit



- 6. Close the Low Pressure side of the manifold gauge, and turn o the vacuum pump.
- 7. Wait for 5 minutes, then check that there has been no change in system pressure.
- 8. If there is a change in system pressure, refer to Gas Leak Check section for information on how to check for leaks. If there is no change in system pressure, unscrew the cap from the packed valve (high pressure valve).
- 9. Insert hexagonal wrench into the packed valve (high pressure valve) and open the valve by turning the wrench in a 1/4 counterclockwise turn. Listen for gas to exit the system, then close the valve after 5 seconds.
- 10. Watch the Pressure Gauge for one minute to make sure that there is no change in pressure. The Pressure Gauge should read slightly higher than atmospheric pressure.
- 11. Remove the charge hose from the service port.



- 12. Using hexagonal wrench, fully open both the high pressure and low pressure valves.
- 13. Tighten valve caps on all three valves (service port, high pressure, low pressure) by hand. You may tighten it further using a torque wrench if needed.

NOTE ON ADDING REFRIGERANT

A CAUTION -

DO NOT mix refrigerant types.

Some systems require additional charging depending on pipe lengths. The standard pipe length varies according to local regulations. For example, in North America, the standard pipe length is 7.5m (25'). In other areas, the standard pipe length is 5m (16'). The refrigerant should be charged from the service port on the outdoor unit's low pressure valve. The additional refrigerant to be charged can be calculated using the following formula:

	Liquid Side Diameter				
	ф6.35(1/4")	ф9.52(3/8″)	ф12.7(1/2")		
R410A: (metering device in the indoor unit)	(Total pipe length - standard pipe length) x30g(0.32oZ)/m(ft)	(Total pipe length - standard pipe length) x65g(0.69oZ)/m(ft)	(Total pipe length - standard pipe length) x115g(1.23oZ)/m(ft)		
R410A: (metering device in the outdoor unit)	(Total pipe length - standard pipe length) x15g(0.16oZ)/m(ft)	(Total pipe length - standard pipe length) x30g(0.32oZ)/m(ft)	(Total pipe length - standard pipe length) x65g(0.69oZ)/m(ft)		
R32:	(Total pipe length - standard pipe length)x 12g(0.13oZ)/m(ft)	(Total pipe length - standard pipe length)x 24g(0.26oZ)/m(ft)	(Total pipe length - standard pipe length)x 40g(0.42oZ)/m(ft)		

TEST RUN

CAUTION

Failure to perform the test run may result in unit damage, property damage, or personal injury.

Before test run

A test run must be performed after the entire system has been completely installed. Confirm the following points before performing the test:

- a) Indoor and outdoor units are properly installed.
- b) Piping and wiring are properly connected.
- c) No obstacles near the inlet and outlet of the unit that might cause poor performance or product malfunction.
- d) Refrigeration system does not leak.
- e) Drainage system is unimpeded and draining to a safe location.
- f) Insulation of piping and duct is properly installed.
- g) Grounding wires are properly connected.
- h) Length of the piping and additional refrigerant capacity have been recorded.
- i) Power voltage is the correct voltage for the air conditioner

Test run instryctions

- 1. Open both the liquid and gas service valves.
- 2. Turn on the main power switch and allow the unit to warm up.
- 3. Set the air conditioner to COOL mode.
- 4. For the Indoor Unit
 - a.Double check to see if the room temperature is being registered correctly.
 - b. Ensure the manual buttons on the indoor unit works properly.
 - c.Check to see that the drainage system is unimpeded and draining smoothly.
 - d.Ensure there is no vibration or abnormal noise during operation.

- 5. For the Outdoor Unit
 - a. Check to see if the refrigeration system is leaking.
 - b. Make sure there is no vibration or abnormal noise during operation.
 - c. Ensure the wind, noise, and water generated by the unit do not disturb your neighbors or pose a safety hazard.
- 6. Drainage Test
 - a. Ensure the drainpipe flows smoothly. New buildings should perform this test before finishing the ceiling.
 - b. Turn on the main power switch and run the air conditioner in COOL mode.
 - c. Check to see that the water is discharged. It may take up to one minute before the unit begins to drain depending on the drainpipe.
 - d. Make sure that there are no leaks in any of the piping.
 - e. Stop the air conditioner. Turn o the main power switch and reinstall the test cover.

NOTICE

If the unit malfunctions or does not operate according to your expectations, please refer to the Troubleshooting section of Service Manual before calling customer service.

24V SIGNAL CHART

	24V input terminal											
Mode	Priority	G	Y1	Y/Y2	В	W	W1	W2	E/AUX	DH/DS/BK	Fan speed	Display
OFF	/	0	0	0	0	0	0	0	0	*	OFF	0
FAN		1	0	0	*	0	0	0	0	*	Low	1
Cooling stage 1		*	1	0	0	0	0	0	0	1	Mid	2
Cooling stage 2	6	*	*	1	0	0	0	0	0	1	High	3
Dehumidification		*	1	0	0	0	0	0	0	0	Low	4
Dehumidification		*	*	1	0	0	0	0	0	0	Low	5
Heat pump stage 1		*	1	0	1	0	0	0	0	1	Mid	6
Heat pump stage 2	5	*	*	1	1	0	0	0	0	1	High	7
Heat pump stage 2		*	*	*	*	1	0	0	0	1	High	,
Electric heater kit 1		*	0	0	*	0	1	0	0	*	Turbo	0
Electric heater kit 2	3	*	0	0	*	0	0	1	0	*	Turbo	8
Electric heater kit 1 and kit 2		*	0	0	*	0	1	1	0	*	Turbo	9
Heat pump stage 1 + Electric heater kit 1		*	1	0	1	0	1	0	0	1	Turbo	
Heat pump stage 1 + Electric heater kit 2		*	1	0	1	0	0	1	0	1	Turbo	
Heat pump stage 2 + Electric heater kit 1		*	*	1	1	0	1	0	0	1	Turbo	10
Heat pump stage 2 + Electric heater kit 1		*	*	*	*	1	1	0	0	1	Turbo	10
Heat pump stage 2 + Electric heater kit 2		*	*	1	1	0	0	1	0	1	Turbo	
Heat pump stage 2 + Electric heater kit 2	4	*	*	*	*	1	0	1	0	1	Turbo	
Heat pump stage 1 + Electric heater kit 1 and kit 2		*	1	0	1	0	1	1	0	1	Turbo	
Heat pump stage 2 + Electric heater kit 1 and kit 2		*	*	1	1	0	1	1	0	1	Turbo	11
Heat pump stage 2 + Electric heater kit 1 and kit 2		*	*	*	*	1	1	1	0	1	Turbo	
Emergency heat	1	*	*	*	*	*	*	*	1	*	Turbo	12
Heating zone control		*	1	0	1	0	*	*	0	0	Low	
Heating zone control	2	*	*	1	1	0	*	*	0	0	Low	
Heating zone control		*	*	*	*	1	*	*	0	0	Low	40
Heating zone control		*	0	0	*	0	1	0	0	0	Low	13
Heating zone control		*	0	0	*	0	0	1	0	0	Low	
Heating zone control		*	0	0	*	0	1	1	0	0	Low	

Note:

1: 24V signal

0: No 24V signal

*: 1 or 0.

The AUU will turn off if the 24V input cannot meet the table.





TECHNICAL BULLETIN Heat Sink Compound (Thermal Paste)

Make sure to use Heat Sink Compound (**not provided**) when replacing Mini-Split electronic boards. Clean up thoroughly old paste on chips located underneath the board, and radiator (fin surface). *Evenly spread* new paste on chips and radiator, and gently screw board back on radiator to maximize heat exchange.