

ComfortStar®

INSTALLATION & OWNER'S MANUAL

ROOFTOP PACKAGE

Thank you very much for purchasing our air conditioner,
Before using your air conditioner, please read this manual carefully and keep it for future reference.

General Description

As the name Rooftop signifies, this unit is generally installed on the top of the roof. Also the Single Package signifies that both condenser and evaporator are enclosed in a single body (same as window type). In fact, The unit can be ideal for either rooftop or on-the-ground installation. The unit is provided with excellent performances that can be operated up to 115°F of maximum ambient temperature.

The unit is used along with ducts and has flexible air flow as per installation conditions.

This unit is ideal for Single story and Double story houses as they offer high static. With its easy installation and simple controlling system, this product is suitable for Factories, Shopping malls, Multiplex, Hotels etc.

At present, the unit capacity range goes from 3 to 5 tons.




A lot of information regarding the design & installation of this system is provided in this publication. Please utilize all the information for conducting your business efficiently, and make sure the specification, dimension or others technical data are same as provided in engineering data book before you start the project.

We look forward to your continuing support.

Table of contents

CONTENT	PAGE
ACCESSORIES-----	1
GENERAL INFORMATION-----	1
DIMENSIONAL DATA-----	2
INSTALLATION-----	3
ELECTRICAL WIRING-----	4
OPERATING CONDITIONS -----	7
PHYSICAL DATA-----	8
WIND PRESSURE CURVE-----	9
PERFORMANCE DATA-----	11
START - UP-----	15
SYSTEM OPERATION -----	15
MAINTENANCE-----	16

1. ACCESSORIES

NAME OF ACCESSORIES	Q'ty	Qutime
MANUAL	1	—
DRAIN OUTLET	1	
SNAP RING	1	
DRAIN PIPE	1	

2. GENERAL INFORMATION



INSPECTION

- Read this entire manual before beginning installation procedures.
- Check for damage after the unit is unloaded. Report promptly, to the carrier, any damage found to the unit. Do not drop the unit.
- Check the unit's nameplate to determine if the unit is correct or the intended application. The power supply must be adequate for both the unit and all accessories.



CAUTION

- Bodily injury can result from high voltage electrical components, fast moving fans. For protection from these inherent hazards during installation and servicing, the electrical supply must be disconnected.
- If operationg checks must be performed with the unit operating, It is the technicians responsibility to recognize these hazards and proceed safely.

Read this manual carefully before attempting to install, operate, or perform maintenance on this unit. Installation and maintenance should be performed by qualified service technicians only.

Reconnect all grounding devices. All parts of this product capable of conducting electrical current are grounded. If grounding wires, screws, straps, clips nuts or washers used to complete a path to ground are removed for service, they must be returned to their original position and properly fastened.



WARNING

- Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

- Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices and where property-damage-only accidents could occur.



NOTE

- Warnings and Cautions appear at appropriate locations throughout this manual.
- Read these carefully.



WARNING

- An all-pole disconnection switch having a contact separation of at least 3mm in all poles should be connected in fixed wiring.
- The temperature of refrigerant circuit will be high, please keep the interconnection cable away from the copper tube.
- The appliance should not be used by children without supervision.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Disconnect the power supply before cleaning and maintenance.



DISPOSAL: Do not dispose this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.

- Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.
- Contact you local government for information regarding the collection systems available.
- If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

3. DIMENSIONAL DATA




Figure 1

4. INSTALLATION

4.1 LOCATIONS AND RECOMMENDATIONS

- The unit is designed for outdoor installations only. The unit may be installed directly on wood flooring or on Class A, Class B, or Class C roof covering material.
- Location of the unit must allow service clearance around it. Clearance of the unit must be given careful consideration.
- Outdoor coils must have an unlimited supply of air.
- Check the handling facilities to ensure the safety of personnel and the unit(s).
- Caution must be taken at all times to avoid Personal injuries and/or damage to equipment.
- The unit must be mounted level for proper drainage of water through the holes in the base pan.
- The unit must not be exposed to direct roof water runoff.
- Flexible duct connectors must be of a flame retardant material. All duct work outside of the structure must be insulated and weatherproofed in accordance with local codes.
- Holes through exterior walls must be sealed in accordance with local codes.
- All fabricated outdoor ducts should be as short as possible.

4.2 ROOFTOP INSTALLATION

For roof top applications using a field fabricated frame and ducts, use the following procedure:

- Roof structure must be able to support the weight of the unit and its options and/or accessories. Unit must be installed on a solid level roof curb or appropriate angle iron frame.




Figure 2

- The frame must be located and secured by bolting or welding to the roof. Flashing is required.
- The hole in the roof must be prepared in advance of installing the unit.
- Secure the ducts to the roof.
- Place the unit on the frame or roof curb.
- Insulate any ductwork outside of the structure with at least two (2) inches of insulation and then weatherproof. There must be a weatherproof seal where the duct enters the structure.
- Secure the unit to the frame or roof curb.
- Complete the installation according to the instructions in the following sections of this manual.

4.3 ON-THE-GROUND INSTALLATION

For ground level installations, the unit should be positioned on a pad with a minimum thickness of 100 mm. The length and width of the pad should be at least 150 mm greater than the unit base rails. The unit must be level on the pad. The pad must not come in contact with the structure. Be sure the outdoor portion of the supply and return air ducts are as short as possible.

Proceed with the installation as follows:

- Place the unit on the pad.
- Attach the supply and return air ducts to the unit.
- Insulate any ductwork outside of the structure with at least 2 inches of insulation and weatherproof. There must be a weatherproof seal where the duct enters the structure.
- Complete the installation according to the instructions in the following sections of this manual.




Figure 3

4.4 MAXIMUM FOUNDATION GRADIENT

Note: Make sure that Condensate Drain side is not higher than the other side.




Figure 4

4.5 CONDENSATE DRAIN PIPING

Note: Twist drain outlet into drain connection hole, sheathe drain pipe, lock in the snap ring.




Figure 5

4.6 DUCTWORK

All conditioned air ductwork should be insulated to minimize heating and cooling duct losses. Use a minimum of two (2) inches of insulation with a vapor barrier. The outside ductwork must be weatherproofed between the unit and the building.

When attaching ductwork to a horizontal unit, provide a flexible watertight connection to prevent noise transmission from the unit to the ducts. The flexible connection must be indoors and made out of heavy canvas.

NOTE
Do not draw the canvas taut between the solid ducts.




Figure 6

5. ELECTRICAL WIRING

- **ELECTRICAL POWER**
It is important that proper electrical power be available for the unit. Voltage variation should remain within the limits stamped on the unit nameplate.
- **DISCONNECT SWITCH**
Provide an approved weatherproof disconnect either on the side of the unit or within close proximity and within sight of the unit.
- **OVER CURRENT PROTECTION**
The branch circuit feeding the unit must be protected as shown on the unit rating plate.
- **POWER WIRING**
The power supply lines must be run in weather tight conduit to the disconnect and into the bottom of the unit control box. Provide strain relief for all conduit with suitable connectors. Provide flexible conduit supports whenever vibration transmission may cause a noise problem within the building structure. Be sure all connections are made tight.
- **CONTROL WIRING (CLASS II)**
Low voltage control wiring should not be run in conduit with power wiring unless Class 1 wire of proper voltage rating is used. Make connections as shown on the unit wiring diagram. Do not short thermostat wires since this will damage the control-transformer.

Suggestion: thermostat choose Non-programmed electrical thermostat series such as
1. CSW23B or CSW25B.

IMPORTANT: Upon completion of wiring check all electrical connections, including factory wiring within the unit, make sure all connections are tight. Replace and secure all electrical box covers and access doors before leaving the unit or turning on the power to the unit.



CAUTION

If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.


An all-pole disconnection device which has at least 3mm separation distance in all pole and a residual current device(RCD)with the rating of above 10mA shall be incorporated in the fixed wiring according to the national rule.

The appliance shall be installed in accordance with national wiring regulations.




NOTE

Knock down the control box access panel, first twist off screws and then up it, the control box access panel is getting out.



WIRING DIAGRAM


CODE	PART NAME
COMP	COMPRESSOR
FAN1	INDOOR FAN
FAN2	OUTDOOR FAN
CAP1	INDOOR FAN CAP
CAP2	OUTDOOR FAN CAP
XP1~2	CONNECTORS
XS1~2	CONNECTORS
RT2	TEMP. SENSOR
KM1	AC CONTACTOR
T5	TRANSFORMER (24V~)
T6	TRANSFORMER
K1	COMP. TOP SENSOR
K2	COMP. TEMP. SWITCH
L-PRO	LOW PRESS SWITCH
XT1	2-WAY TERMINAL
XT2	MIDDLE TERMINAL
CAP3~4	COMP RUNNING CAP




For cooling only,
48000Btu/h, 208-230V/1PH/60Hz

WIRING DIAGRAM

CODE	PART NAME
COMP	COMPRESSOR
FAN1	INDOOR FAN
FAN2	OUTDOOR FAN
CAP1	INDOOR FAN CAP
CAP2	OUTDOOR FAN CAP
XP1~2	CONNECTORS
XS1~2	CONNECTORS
RT2	TEMP. SENSOR
KM1	AC CONTACTOR (24V~)
T5	TRANSFORMER (24V~)
T6	TRANSFORMER
K1	COMP. TOP SENSOR
K2	COMP. TEMP. SWITCH
L-PRO	LOW PRESS SWITCH
XT1	2-WAY TERMINAL
XT2	MIDDLE TERMINAL
CAP3~4	COMP RUNNING CAP



For Cooling Only,
60000Btu/h, 208-230V/1PH/60Hz



TYPE		36000Btu/h (Cooling only)	48000Btu/h (Cooling only)	60000Btu/h (Cooling only)	60000Btu/h (Cooling only)
POWER	PHASE	1-PHASE	1-PHASE	1-PHASE	3-PHASE
	FREQUENCY AND VOLT	208-230V~, 60Hz	208-230V~, 60Hz	208-230V~, 60Hz	208-230V~, 60Hz
CIRCUIT BREAKER/FUSE (A)		40	60	80	50
POWER WIRING (mm2)		3×4.0	3×10	3×10	5×8.0
SIGNAL WIRING (mm2)		4×0.8	4×0.8	4×0.8	4×0.8

The power cord type designation is H07RN-F.

6. OPERATING CONDITIONS

For proper performance, run the unit under the following temperature conditions:

Cooling operation	Outdoor temperature: 70 to 115°F
	Room temperature: 62 to 86°F
	Caution Room relative humidity less than 80%. If the unit operates in excess of this figure, the surface of the unit may attract condensation.


7. PHYSICAL DATA

Table 7-1


Component		Physical Data		
Nominal Capacity (Btu/h)		36000	48000	60000
ARI COOLING PERFORMANCE	Nominal Tonnage	3.0	4.0	5.0
	SEER	10	10	10
	Refrigerant type	R-410A	R-410A	R-410A
DIMENSIONS	Length (mm)	1116	1116	1116
	Width (mm)	744	744	744
	Height (mm)	830	830	830
CONDENSER COIL DATA	Fins per inch	17	17	17
	Tube diameter (in.)	9/32	9/32	9/32
	Circuitry Type	Intertwined	Intertwined	Intertwined
EVAPORATOR COIL DATA	Rows	3	3	4
	Fins per inch	17	17	17
	Tube diameter (in.)	9/32	9/32	9/32
	Refrigerant control	Capillary tude	Capillary tude	Capillary tude
CONDENSER FAN DATA	Quantity	1	1	1
	Fan diameter (mm)	550	550	550
	Type	Prop	Prop	Prop
	Drive type	Direct	Direct	Direct
	No. Speeds	1	1	1
	Number of motors	1	1	1
	RPM	1090	1090	1090
	Nominal total CFM	3800	3600	3600
DIRECT DRIVE EVAP FAN DATA	Quantity	1	1	1
	Fan diameter (mm)	273	273	273
	Type	Centrifugal	Centrifugal	Centrifugal
	Drive type	Direct	Direct	Direct
	No. Speeds	3	3	3
	Number of motors	1	1	1
	RPM	934	1013	1087
	Nominal total CFM (50Pa)	1450	1650	1655

8. WIND PRESSURE CURVE


36000Btu/h 208-230V~ 60Hz



48000Btu/h 208-230V~ 60Hz



60000Btu/h 208-230V~ 60Hz
60000Btu/h 208-230V 3N~ 60Hz



9. PERFORMANCE DATA

COOLING PERFORMANCE DATA—36K(208-230V~ 60Hz)

Ambient Temperature (°F)	Entering Wet Bulb (°F)	Air Flow	CFM	1200			
		Ent DB	(°F)	75	80	85	90
75	61	TGC	35.9	36.0	36.2	36.5	
		SHC	28.2	32.2	35.4	36.5	
		INPUT[kW]	3.20	3.40	3.50	3.65	
		67	TGC	39.5	39.6	39.8	40.1
			SHC	23.8	28.9	33.2	36.9
			INPUT[kW]	3.24	3.44	3.54	3.69
		73	TGC	42.0	42.1	42.3	42.6
			SHC	17.2	23.4	28.8	33.4
			INPUT[kW]	3.27	3.47	3.57	3.72
85	61	TGC	33.3	33.4	33.6	33.9	
		SHC	27.9	32.3	33.6	33.9	
		INPUT[kW]	3.59	3.79	3.89	4.04	
	67	TGC	36.8	36.9	37.1	37.4	
		SHC	22.9	28.4	33.2	37.4	
		INPUT[kW]	3.62	3.82	3.92	4.07	
	73	TGC	39.4	39.5	39.7	40.0	
		SHC	16.3	22.5	28.2	33.3	
		INPUT[kW]	3.65	3.85	3.95	4.10	
95	61	TGC	30.6	30.7	30.9	31.2	
		SHC	27.1	30.7	30.9	31.2	
		INPUT[kW]	3.97	4.17	4.27	4.42	
	67	TGC	34.1	34.2	34.4	34.7	
		SHC	21.9	27.7	27.2	34.7	
		INPUT[kW]	3.98	4.00	4.10	4.25	
	73	TGC	36.7	36.8	37.0	37.3	
		SHC	15.3	21.5	27.5	32.9	
		INPUT[kW]	4.03	4.23	4.33	4.48	
105	61	TGC	28.0	28.1	28.3	28.6	
		SHC	26.3	28.1	28.3	28.6	
		INPUT[kW]	4.35	4.55	4.65	4.80	
	67	TGC	31.5	31.6	31.8	32.1	
		SHC	20.9	26.8	31.8	32.1	
		INPUT[kW]	4.38	4.58	4.68	4.83	
	73	TGC	34.1	34.2	34.4	34.7	
		SHC	14.4	20.5	26.6	32.4	
		INPUT[kW]	4.41	4.61	4.71	4.86	
115	61	TGC	25.3	25.4	25.6	25.9	
		SHC	25.0	25.4	25.6	25.9	
		INPUT[kW]	4.73	4.93	5.03	5.18	
	67	TGC	28.9	29.0	29.2	29.5	
		SHC	19.7	25.8	29.2	29.5	
		INPUT[kW]	4.76	4.96	5.06	5.21	
	73	TGC	31.4	31.5	31.7	32.0	
		SHC	13.3	19.4	25.5	31.4	
		INPUT[kW]	4.80	5.00	5.10	5.25	

Notes:

1. All capacities are gross and have not considered indoor fan heat. To obtain NET cooling capacity subtract indoor fan heat.
2. DB = Dry Bulb Temperature (°F)
3. CFM = Cubic Feet per minute
4. TGC=Total Gross Capacity. (Unit: kBtu/h)
5. SHC=Sensible Heat Capacity. (Unit: kBtu/h)
6. IPT=Input power. (Unit: kW)

COOLING PERFORMANCE DATA—48K(208-230V~ 60Hz)

Ambient Temperature (°F)	Entering Wet Bulb (°F)	Air Flow		1600			
		Ent DB	CFM (°F)	75	80	85	90
75	61	TGC	49.1	49.2	49.4	49.7	
		SHC	34.2	39.6	43.9	47.6	
		INPUT[KW]	4.39	4.59	4.69	4.84	
		67	TGC	54.1	54.2	54.4	54.7
			SHC	27.7	34.7	40.6	45.5
			INPUT[KW]	4.44	4.64	4.74	4.89
		73	TGC	57.5	57.6	57.8	58.1
			SHC	18.4	26.9	34.2	40.3
			INPUT[KW]	4.49	4.69	4.79	4.94
	85	61	TGC	45.5	45.6	45.8	46.1
			SHC	34.0	40.0	45.1	46.1
			INPUT[KW]	4.91	5.11	5.21	5.36
67		TGC	50.4	50.5	50.7	51.0	
		SHC	26.9	34.4	40.9	46.5	
		INPUT[KW]	4.96	5.16	5.26	5.41	
73		TGC	53.9	54.0	54.2	54.5	
		SHC	17.5	26.0	33.7	40.6	
		INPUT[KW]	5.01	5.21	5.31	5.46	
95		61	TGC	41.9	42.0	42.2	42.5
			SHC	33.4	39.9	42.2	42.5
			INPUT[KW]	5.43	5.63	5.73	5.88
	67	TGC	46.7	46.8	47.0	47.3	
		SHC	25.8	33.7	32.9	46.9	
		INPUT[KW]	5.46	5.48	5.58	5.73	
	73	TGC	50.3	50.4	50.6	50.9	
		SHC	16.5	25.0	33.1	40.4	
		INPUT[KW]	5.53	5.73	5.83	5.98	
	105	61	TGC	38.3	38.4	38.6	38.9
			SHC	32.5	38.4	38.6	38.9
			INPUT[KW]	5.96	6.16	6.26	6.41
67		TGC	43.2	43.3	43.5	43.8	
		SHC	24.8	32.9	40.3	43.8	
		INPUT[KW]	6.00	6.20	6.30	6.45	
73		TGC	46.7	46.8	47.0	47.3	
		SHC	15.5	23.9	32.2	39.9	
		INPUT[KW]	6.05	6.25	6.35	6.50	
115		61	TGC	34.6	34.7	34.9	35.2
			SHC	31.1	34.7	34.9	35.2
			INPUT[KW]	6.48	6.68	6.78	6.93
	67	TGC	39.5	39.6	39.8	40.1	
		SHC	23.4	31.7	39.3	40.1	
		INPUT[KW]	6.52	6.72	6.82	6.97	
	73	TGC	43.0	43.1	43.3	43.6	
		SHC	14.5	22.7	31.0	39.0	
		INPUT[KW]	6.57	6.77	6.87	7.02	

Notes:

1. All capacities are gross and have not considered indoor fan heat. To obtain NET cooling capacity subtract indoor fan heat.
2. DB = Dry Bulb Temperature (°F)
3. CFM = Cubic Feet per minute
4. TGC=Total Gross Capacity. (Unit: kBtu/h)
5. SHC=Sensible Heat Capacity. (Unit: kBtu/h)
6. IPT=Input power. (Unit: kW)

COOLING PERFORMANCE DATA—60K(208-230V~ 60Hz)

Ambient Temperature (°F)	Air Flow	Ent DB	CFM (°F)	1750				
				75	80	85	90	
				75	80	85	90	
75	75	61	TGC	59.9	60.0	60.2	60.5	
			SHC	43.6	50.1	55.3	59.7	
			INPUT[KW]	5.37	5.57	5.67	5.82	
			67	TGC	65.8	65.9	66.1	66.4
				SHC	35.7	44.2	51.3	57.2
				INPUT[KW]	5.42	5.62	5.72	5.87
			73	TGC	70.1	70.2	70.4	70.7
				SHC	24.5	34.9	43.7	51.2
				INPUT[KW]	5.48	5.68	5.78	5.93
85	75	61	TGC	55.4	55.5	55.7	56.0	
			SHC	43.1	50.4	55.7	56.0	
			INPUT[KW]	6.00	6.20	6.30	6.45	
		67	TGC	61.4	61.5	61.7	62.0	
			SHC	34.6	43.7	51.6	58.3	
			INPUT[KW]	6.06	6.26	6.36	6.51	
		73	TGC	65.7	65.8	66.0	66.3	
			SHC	23.3	33.7	43.0	51.3	
			INPUT[KW]	6.12	6.32	6.42	6.57	
95	75	61	TGC	51.0	51.1	51.3	51.6	
			SHC	42.2	50.1	51.3	51.6	
			INPUT[KW]	6.64	6.84	6.94	7.09	
		67	TGC	56.9	57.0	57.2	57.5	
			SHC	33.2	42.8	41.8	57.5	
			INPUT[KW]	6.68	6.70	6.80	6.95	
		73	TGC	61.2	61.3	61.5	61.8	
			SHC	21.9	32.3	42.0	50.9	
			INPUT[KW]	6.76	6.96	7.06	7.21	
105	75	61	TGC	46.6	46.7	46.9	47.2	
			SHC	40.9	46.7	46.9	47.2	
			INPUT[KW]	7.28	7.48	7.58	7.73	
		67	TGC	52.6	52.7	52.9	53.2	
			SHC	31.7	41.6	50.6	53.2	
			INPUT[KW]	7.34	7.54	7.64	7.79	
		73	TGC	56.8	56.9	57.1	57.4	
			SHC	20.6	30.8	40.8	50.2	
			INPUT[KW]	7.40	7.60	7.70	7.85	
115	75	61	TGC	42.2	42.3	42.5	42.8	
			SHC	39.2	42.3	42.5	42.8	
			INPUT[KW]	7.92	8.12	8.22	8.37	
		67	TGC	48.2	48.3	48.5	48.8	
			SHC	30.0	40.1	48.5	48.8	
			INPUT[KW]	7.98	8.18	8.28	8.43	
		73	TGC	52.4	52.5	52.7	53.0	
			SHC	19.2	29.2	39.3	49.0	
			INPUT[KW]	8.03	8.23	8.33	8.48	

Notes:

1. All capacities are gross and have not considered indoor fan heat. To obtain NET cooling capacity subtract indoor fan heat.
2. DB = Dry Bulb Temperature (°F)
3. CFM = Cubic Feet per minute
4. TGC=Total Gross Capacity. (Unit: kBtu/h)
5. SHC=Sensible Heat Capacity. (Unit: kBtu/h)
6. IPT=Input power. (Unit: kW)

COOLING PERFORMANCE DATA—60K(208-230V 3N~ 60Hz)

Ambient Temperature (°F)	Air Flow	Ent DB	CFM (°F)	1750					
				75	80	85	90		
75	Entering Wet Bulb (°F)	61	TGC	60.5	60.6	60.8	61.1		
			SHC	41.8	48.4	53.7	58.1		
			INPUT[KW]	5.29	5.49	5.59	5.74		
			67	TGC	66.5	66.6	66.8	67.1	
				SHC	33.7	42.3	49.4	55.4	
				INPUT[KW]	5.35	5.55	5.65	5.80	
			73	TGC	70.8	70.9	71.1	71.4	
				SHC	22.2	32.7	41.6	49.2	
				INPUT[KW]	5.40	5.60	5.70	5.85	
		85	Entering Wet Bulb (°F)	61	TGC	56.0	56.1	56.3	56.6
					SHC	41.5	48.9	55.0	56.6
					INPUT[KW]	5.92	6.12	6.22	6.37
67	TGC			62.1	62.2	62.4	62.7		
	SHC			32.7	42.0	49.9	56.7		
	INPUT[KW]			5.97	6.17	6.27	6.42		
73	TGC			66.3	66.4	66.6	66.9		
	SHC			21.1	31.6	41.0	49.4		
	INPUT[KW]			6.03	6.23	6.33	6.48		
95	Entering Wet Bulb (°F)			61	TGC	51.6	51.7	51.9	52.2
					SHC	40.9	48.9	51.9	52.2
					INPUT[KW]	6.54	6.74	6.84	6.99
		67	TGC	57.5	57.6	57.8	58.1		
			SHC	31.5	41.1	40.2	57.2		
			INPUT[KW]	6.58	6.60	6.70	6.85		
		73	TGC	61.9	62.0	62.2	62.5		
			SHC	19.9	30.4	40.3	49.3		
			INPUT[KW]	6.66	6.86	6.96	7.11		
		105	Entering Wet Bulb (°F)	61	TGC	47.1	47.2	47.4	47.7
					SHC	39.7	47.2	47.4	47.7
					INPUT[KW]	7.17	7.37	7.47	7.62
67	TGC			53.1	53.2	53.4	53.7		
	SHC			30.1	40.1	49.1	53.7		
	INPUT[KW]			7.23	7.43	7.53	7.68		
73	TGC			57.4	57.5	57.7	58.0		
	SHC			18.7	29.0	39.2	48.6		
	INPUT[KW]			7.28	7.48	7.58	7.73		
115	Entering Wet Bulb (°F)			61	TGC	42.6	42.7	42.9	43.2
					SHC	38.0	42.7	42.9	43.2
					INPUT[KW]	7.80	8.00	8.10	8.25
		67	TGC	48.7	48.8	49.0	49.3		
			SHC	28.6	38.7	48.1	49.3		
			INPUT[KW]	7.85	8.05	8.15	8.30		
		73	TGC	53.0	53.1	53.3	53.6		
			SHC	17.5	27.6	37.8	47.6		
			INPUT[KW]	7.91	8.11	8.21	8.36		

Notes:

1. All capacities are gross and have not considered indoor fan heat. To obtain NET cooling capacity subtract indoor fan heat.
2. DB = Dry Bulb Temperature (°F)
3. CFM = Cubic Feet per minute
4. TGC=Total Gross Capacity. (Unit: kBtu/h)
5. SHC=Sensible Heat Capacity. (Unit: kBtu/h)
6. IPT=Input power. (Unit: kW)

10. START-UP

■ PACKAGING AND COMPONENTS

- Is the unit properly located and level with the proper clearance?
- Is the duct work correctly sized, run, taped, insulated, and weatherproofed with proper unit arrangement? See Ductwork Installation section.
- Is the wiring properly sized and run according to the unit wiring diagram?
- Are all the wiring connections, including those in the unit, tight?
- Has the unit been properly grounded and fused with the recommended fuse size? See Wiring Data.
- Have the air conditioning systems been checked at the service ports for charge and leak tested if necessary?
- Does the condenser fan and indoor blower turn free without rubbing, and are they tight on the shafts?
- Has the indoor blower speed been determined and the proper speed been set? See the Unit Wiring Diagram.
- Are all covers and access panels in place to prevent air loss and safety hazards?



CAUTION

Before starting the system on the cooling cycle, turn the thermostat switch to OFF and close the unit disconnect switch. This procedure energizes the compressor crankcase heater, vaporizing any liquid refrigerant in the crankcase. This is a precaution against foaming at startup which could damage the compressor bearings. Allow the crankcase heater to operate a minimum of eight (8) hours, if crankcase heater has been installed.

■ STARTING THE UNIT IN THE COOLING MODE

To start the unit in the cooling mode, set the thermostat system switch to COOL and move the thermostat COOL indicator to a setting below room temperature. The condenser (outdoor) fan motor compressor and evaporator (indoor) fan motor will operate automatically.

■ VOLTAGE

With the compressor operating, check the line voltage at the unit. The voltage should be within the range shown on the unit nameplate.

If low voltage is encountered, check the size and length of the supply line from the main disconnect to the unit. The line may be undersized for the length of the run.

■ COOLING SHUT DOWN

Place the system selector in the OFF position or reset thermostat at a setting above room temperature.

Do not de-energize the main power disconnect except when unit is to be serviced. Power is required to keep the heat pump compressor warm and boil off refrigerant in the compressor.

11. SYSTEM OPERATION

■ LED DISPLAY

The control would display any fault code that is currently active using the LED. The control will display the fault code, when the LEDS are flashing quickly, there is something wrong with the system. Refer to below table for detail fault code.

Function:

1. the compressor and indoor fan will start when the system is energized, outdoor fan starts with compressor.
2. When the system is de-energized, the outdoor fan and compressor would close soon, but the indoor fan would closed later.

■ Operational Codes:

NUM	CODE	LED1 (Red)	LED2 (Yellow)	LED3 (Green)
1	STANDBY	OFF	OFF	ON
2	FUNCTION	ON	ON	ON
3	PHASE-MISSING	FLASH	FLASH	FLASH
	PHASE-ERROR			
4	VENT PROTECTION	FLASH	FLASH	FLASH
5	T2 SENSOR FAILURE	FLASH	OFF	FLASH
6	T2 EVAPORATOR LOW TEMP. PROTECTION	OFF	FLASH	OFF
7	T2 EVAPORATOR HIGH TEMP. PROTECTION	FLASH	ON	ON
8	WIRE CONTROLLER INPUT FAILURE	FLASH	FLASH	ON
9	COMPRESSOR OVERCURRENT PROTECTION	OFF	OFF	FLASH
10	COMPRESSOR-INHALING LOW PRESSURE PROTECTION	FLASH	ON	FLASH

■ LOW PRESSURE SWITCH

The control will detect the status of low pressure switch, which is normally close. If the low pressure switch is open during the first time of power supply, the control will de-energized the compressor. If low pressure switch protection appears 3 times in 20 minutes, the control should be restored by switch off the power supply. The control will ignore the low pressure switch input during the following conditions: defrost operation, 4 minutes following the completion of a defrost cycle, first 5 minute of compressor operation.

■ INDICATIONS OF PROPER OPERATION

when the LEDS in a lighting states, no matter which one, it is means the system runs properly.

12. MAINTENANCE

■ ROUTINE MAINTENANCE BY OWNER

You can do some of the periodic maintenance functions for your unit yourself; this includes cleaning the permanent air filters, cleaning the unit cabinet, cleaning the condenser coil, and conducting a general unit inspection on a regular basis.

■ CLEANING THE AIR FILTER

1. Dismantle the air filter.
 - Twist of screws, then the filter baffle gets out.
 - Drag out filter.




Figure 7

2. Clean the air filter (Vacuum cleaner or pure water may be used to clean the air filter. If the dust accumulation is too heavy, please use soft brush and mild detergent to clean it and dry out.)




Figure 8

- The air-in side should face up when using vacuum cleaner.
- The air-in side should face down when using water.



CAUTION

Do not dry out the air filter under direct sunshine or with fire.

3. Re-install the air filter

■ CONDENSER COIL

Unfiltered air circulates through the unit's condenser coil and can cause the coil's surface to become clogged with dust, dirt, etc. To clean the coil, vertically (i.e., with the fins) stroke the coil surface with a soft-bristled brush. Be sure to keep all vegetation away from the condenser coil area.

■ MAINTENANCE PERFORMED BY SERVICEMAN-COOLING SEASON

To keep your unit operating safely and efficiently, the manufacturer recommends that a qualified serviceman check the entire system at least once each year and any other time that you feel one is needed. Your serviceman should examine these areas of your unit:

- filters
- motors and drive system components
- economizer gaskets (for possible replacement)
- safety controls (for mechanical cleaning)
- electrical components and wiring (for possible replacement and connection tightness)
- condensate drain (for cleaning)
- unit duct connections (to see that they are physically sound and sealed to the unit casing)
- unit mounting support (for structural integrity)
- the unit (for obvious unit deterioration)



CAUTION

Do not operate the unit without the evaporator fan access panel in place. Reinstall the access panel after performing any maintenance procedures on the fan. Operating the unit without the access panel properly installed may result in severe personal injury or death.