




Service Manual

**Outdoor Unit: MRH32-24(33D)
MRH32-36(33E)
MRH32-48(33F)
MRH32-60(33G)**



RECOGNIZE THIS SYMBOL AS A SAFETY PRECAUTION

ATTENTION INSTALLING PERSONNEL

Prior to installation, thoroughly familiarize yourself with this Installation Manual. Observe all safety warnings.

During installation or repair, caution is to be observed

It is your responsibility to install the product safely and to educate the customer on its safe use

Eair LLC

12201 N.W. 107th Avenue, Medley, FL 33178

www.comfortstarusa.com

Content

| | |
|---|----|
| Part 1 General Information | 1 |
| Part 2 Component Layout and Refrigerant Circuit..... | 4 |
| Part 3 Wiring Diagram..... | 7 |
| Part 4 Diagnosis and Troubleshooting..... | 16 |

Part 1

General Information

| | |
|------------------------|---|
| 1 Product lineup | 2 |
| 2 Specifications | 3 |

1 Product lineup

| Model | Cooling Capacity (Btu/h) | Heating Capacity (Btu/h) | Appearance |
|----------|-----------------------------|-----------------------------|--|
| MRH32-24 | 24000 | 24000 |  |
| MRH32-36 | 36000 | 34200 |  |
| MRH32-48 | 48000 | 48000 |  |
| MRH32-60 | 54000 | 54000 |  |

2 Specifications

| Outdoor unit | | | MRH32-24 | MRH32-36 | MRH32-48 | MRH32-60 |
|----------------------------------|-------------------------------|-----------|-------------------------------------|-----------------|-------------------------|-----------------|
| Power Supply | Rated Voltage | V, Ph, Hz | 208/230, 1, 60, | 208/230, 1, 60, | 208/230, 1, 60, | 208/230, 1, 60, |
| Cooling | capacity | Btu/h | 24000 | 36000 | 48000 | 54000 |
| | Input | W | 1950 | 3400 | 4900 | 6300 |
| Heating | capacity | Btu/h | 24000 | 34200 | 48000 | 54000 |
| | Input | W | 2050 | 3000 | 4000 | 4700 |
| Outdoor MINIMUM CIRCUIT AMPACITY | | A | 19.0 | 24.0 | 36.0 | 39.0 |
| Outdoor MAX.FUSE | | A | 20 | 30 | 40 | 40 |
| Outdoor Outdoor Air Flow(CFM) | | CFM | 2100.0 | 2800.0 | 3050.0 | 3050.0 |
| Outdoor noise level (Hi) | | dB(A) | 58.0 | 58.0 | 60.0 | 60.0 |
| Connection Wiring | | | 485: AWG 25*3 Shielded, 24V: AWG 20 | | | |
| Communication Type | | | 24V / 485 | 24V / 485 | 24V / 485 | 24V / 485 |
| Throttle type | | | EXV | EXV | EXV | EXV |
| Outdoor unit | Dimension (WxDxH) | inch | 29-9/64x29-9/64x25 | | 29-9/64x29-9/64x32-7/8 | |
| | Packing Demension (WxDxH) | inch | 30-5/16x30-5/16x26-3/16 | | 30-5/16x30-5/16x34-1/16 | |
| | Net/Gross Weight | lbs | 143/151 | 143/151 | 187/196 | 187/196 |
| Refrigerant | Type/charge | oz | R32/84.72 | R32/84.72 | R32/105.9 | R32/105.9 |
| | Additional refrigerant per ft | oz/ft | 0.52 | 0.52 | 0.52 | 0.52 |
| | N.A.Design Pressure | PSI | 609/174 | 609/174 | 609/174 | 609/174 |
| Refrigerant piping | Liquid side/Gas side | inch | (3/8) /(3/4) | (3/8) /(3/4) | (3/8) /(3/4) | (3/8) /(3/4) |
| | Max. refrigerant pipe length | ft | 164 | 246 | 246 | 246 |
| | Max. difference in level | ft | 82 | 98.4 | 98.4 | 98.4 |
| Ambient temp. operation range | Cooling | °F | 5~131 | 5~131 | 5~131 | 5~131 |
| | Heating | °F | -4~75 | -4~75 | -4~75 | -4~75 |


Part 2

Component Layout and Refrigerant Circuit


| | |
|--------------------------------------|---|
| 1 Layout Functional Components | 5 |
| 2 Piping diagrams | 6 |

1 Layout Functional Components


MRH32-24, MRH32-36



MRH32-48, MRH32-60



2 Piping diagrams




| NO. | Component(Outdoor unit) | NO. | Component(Outdoor unit) |
|------|-----------------------------------|-----|--------------------------|
| Com. | Compressor | RCP | Refrigerant cooling pipe |
| TP | Exhaust temperature sensor | GLQ | Filter |
| HP | High pressure switch | LSV | Liquid Stop Valve |
| ST1 | Four-way valve | GSV | Gas Stop Valve |
| T4 | Ambient temperature sensor | PS | Pressure sensor |
| T3 | Condenser coil temperature sensor | ACC | Gas-liquid separator |
| Con. | Condenser | TP | Thermal fuse |
| EEV | Electrical Expansion Valve | LP | Low pressure switch |

Part 3


Wiring Diagram

| | |
|------------------------------------|----|
| 1 Electric wiring diagram | 8 |
| 2 PCB | 9 |
| 3 Low voltage wiring diagram | 11 |


1 Electric wiring diagram




2 PCB



24/36K Outdoor Main Control Board



48/60K Outdoor Main Control Board



Definition and uses of the button

- K1: Press "K1" once to enter the outdoor unit parameter inspection.
- K2: Press "K2" to view the parameters in sequence
- K3: Press "K3" to view the parameters in reverse order.
- K4: "SET" button used to enter forced cooling mode to recover the refrigerant.


Definition of SW1~SW3

| Wire Color Code | | DIP switch status Indicate | | Outdoor Display Board SW1 DIP switch selection | | | Outdoor Display Board SW2 DIP switch selection | | | |
|---|-----------|----------------------------|--------|--|-------|-----|---|-------|-----------------------------|-----------------|
| RD RED | OR ORANGE | ON | 1 | This Indicate OFF (The DIP switch is dialed to the digital side) | SW1.1 | OFF | 24V Control | SW2.1 | OFF | Auto Defrosting |
| BL BLUE | GN GREEN | OFF | 1 | | SW1.2 | ON | RS485 Comm. Mode | ON | Periodically Defrosting | |
| BR BROWN | GY GRAY | | | This Indicate ON (The DIP switch is dialed to the non-digital side) | SW1.3 | OFF | F for Fahrenheit | OFF | Defrost interval 60 minutes | |
| BK BLACK | YE YELLOW | ON | ■ | | SW1.4 | ON | C for Celsius | ON | Defrost interval 30 minutes | |
| WH WHITE | PR PURPLE | OFF | 1 | | SW2.2 | OFF | Heating and cooling | OFF | Normal Defrosting | |
| | | | | | SW2.3 | ON | Single-cooled | ON | Accelerate Defrosting | |
| | | | | | SW2.4 | OFF | Normal Cooling | OFF | Normal Thermostat | |
| | | | | | | ON | Accelerate Cooling | ON | O/B Thermostat | |
| Outdoor Display Board SW3 DIP switch selection | | | | | | | | | | |
| SW3.1 | SW3.2 | SW3.3 | Models | | | | | | | |
| OFF | OFF | OFF | 18K | | | | | | | |
| OFF | OFF | ON | 24K | | | | | | | |
| OFF | ON | OFF | 30K | | | | | | | |
| OFF | ON | ON | 36K | | | | | | | |
| ON | OFF | OFF | 48K | | | | | | | |
| ON | OFF | ON | 60K | | | | | | | |
| SW3.4 | OFF | Normal Heating | | | | | | | | |
| | ON | Accelerate Heating | | | | | | | | |


3 Low voltage wiring diagram

The following wiring diagram are suitable for the Indoor Unit and Outdoor Unit with 24V thermostat


Wiring for 1H and 1C thermostat (no heat pump system model)




Wiring for 1H and 1C thermostat (no heat pump system model)




Wiring for 2H and 1C thermostat (no heat pump system model)




Wiring for 2H and 2C thermostat (no heat pump system model)




Wiring for 3H and 1C thermostat (no heat pump system model)



Wiring for 3H and 2C thermostat (no heat pump system model)




Wiring for 4H and 2C thermostat (no heat pump system model)




Heat Pump System Model

Wiring for 1H and 1C thermostat (heat pump system model)




Wiring for 2H and 1C thermostat (heat pump system model)



Wiring for 2H and 2C thermostat (heat pump system model)


Note: Y1 and Y2 here represents 2 stages of fan cooling only, the compressor modulates separately from the fan.



Wiring for 3H and 1C thermostat (heat pump system model)

Note: Because Y1 and Y2 are jumped, the indoor fan will only run in high stage.


Note: Any time the electric heat elements are active, the indoor fan will run in high stage.




Wiring for 3H and 2C thermostat (heat pump system model)

Note: Y1 and Y2 here represents 2 stages of fan cooling only, the compressor modulates separately from the fan.

Note: Any time the electric heat elements are active, the indoor fan will run in high stage.



Wiring for 4H and 2C thermostat (heat pump system model)



Control Logic:

Indoor unit connector

| Connector | Purpose |
|-----------|--------------------------|
| R | 24V Power Connection |
| C | Common |
| G | Fan Control |
| Y1 | Low Cooling |
| Y2 | High Cooling |
| B | Heating Reversing Valve |
| W1 | Stage 1 Electric Heating |
| W2 | Stage 2 Electric Heating |
| DH | Dehumidification |

Outdoor unit connector

| Connector | Purpose |
|-----------|-------------------------|
| C | Common |
| Y | Cooling |
| B | Heating Reversing Valve |
| W | Defrost control |

Note:

- 1) DH wiring is optional and requires a thermostat with a humidistat. DH functions as Passive Dehumidification and will downstage the indoor fan to first stage. System will operate according to normal sequence of operations if DH wiring is absent.
- 2) Dashed lines in the above thermostat wiring diagrams refer to optional wiring (wiring for Passive Dehumidification Function and/OR Electric Heat). For thermostat wiring please refer to the Owner's Manual of the thermostat.
- 3) B wire must be used with heat pump system only, the reversing valve energizes in heating.

Part 4

Diagnosis and Troubleshooting

| | |
|---|----|
| 1 Error code table | 18 |
| 2 Troubleshooting | 20 |
| 2.1 Safety Precautions | 20 |
| 2.2 ATL Troubleshooting | 23 |
| 2.3 E1/F0 Troubleshooting | 24 |
| 2.4 F4/F5/F6/FC/FE/E2/E3/H8 Troubleshooting | 25 |
| 2.5 E4 Troubleshooting | 26 |
| 2.7 E6 Troubleshooting | 27 |
| 2.7 E8 Troubleshooting | 28 |
| 2.8 E9 Troubleshooting | 29 |
| 2.9 FA/FB Troubleshooting | 30 |
| 2.10 FD Troubleshooting | 31 |
| 2.11 FF/P1/H2 Troubleshooting | 32 |
| 2.12 F9/L0/L1 Troubleshooting | 33 |
| 2.13 P2/H5 Troubleshooting | 34 |
| 2.14 P3 Troubleshooting | 35 |
| 2.15 P4/H6 Troubleshooting | 36 |
| 2.16 P5 Troubleshooting | 37 |
| 2.17 P6 Troubleshooting | 37 |
| 2.18 P7/PC Troubleshooting | 38 |
| 2.19 P8 Troubleshooting | 40 |
| 2.20 P9 Troubleshooting | 41 |
| 2.21 H0 Troubleshooting | 42 |

| | |
|---|----|
| 2.22 The outdoor unit is displaying PRH..... | 42 |
| 3. Temperature Sensor Resistance Characteristics..... | 43 |

1 Error code table

| Error code | Error definition |
|------------|---|
| FA | EEPROM fault (on main PCB) |
| FB | EEPROM fault (on inverter module) |
| H1 | P5 protection appears 3 times in 180 minutes can't be recovered until re-power on |
| H2 | FF protection appears 3 times in 150 minutes can't be recovered until re-power on |
| H3 | PD protection appears 3 times in 180 minutes can't be recovered until re-power on |
| H4 | P8 protection appears 3 times in 120 minutes can't be recovered until re-power on |
| H5 | P2 protection appears 3 times in 240 minutes can't be recovered until re-power on |
| H6 | P4 protection appears 3 times in 100 minutes can't be recovered until re-power on |
| H7 | PC protection appears 3 times in 200 minutes can't be recovered until re-power on |
| H8 | FE protection appears 3 times in 120 minutes can't be recovered until re-power on |
| HC | F7 protection appears 3 times in 180 minutes can't be recovered until re-power on |
| HE | F8 protection appears 3 times in 60 minutes can't be recovered until re-power on |
| H0 | Inverter module and main PCB communication error |
| L0 | DC bus low voltage protection |
| L1 | DC bus high voltage protection |
| FF | High pressure switch fault for 20 minutes |
| P1 | High pressure switch fault for 4 seconds |
| P2 | Low pressure protection in cooling mode |
| P3 | Over current protection |
| P4 | Discharge temperature protection |
| P5 | T3 high temperature protection in cooling mode |
| P6 | Compressor inverter module protection |
| P7 | Indoor unit anti-freezing protection (Applicable only when communication is established between the ComfortStar outdoor unit and the ComfortStar indoor unit via RS485) |
| P8 | IPM high temperature protection |
| P9 | Fan motor inverter module protection |
| PC | Overheat operation protection (Applicable only when communication is established between the ComfortStar outdoor unit and the ComfortStar indoor unit via RS485) |
| PD | High pressure protection in heating mode |
| F0 | Outdoor unit and indoor unit communication error |
| F4 | T4 - Ambient temperature sensor fault |
| F5 | TP - Discharge temperature sensor fault |
| F6 | T3 - Coil temperature sensor fault |
| F7 | T7 temperature sensor fault (not applicable for cooling only unit) |
| F8 | Reserved |
| F9 | AC voltage is too high or too low protection |
| FC | IPM temperature sensor fault |
| FD | Pressure sensor fault |

| | |
|-----|---|
| FE | T3/TP temperature sensor loose protection |
| E1 | Outdoor unit and indoor unit communication error (Applicable only when communication is established between the ComfortStar outdoor unit and the ComfortStar indoor unit via RS485) |
| E2 | Indoor unit T1 temperature sensor fault (Applicable only when communication is established between the ComfortStar outdoor unit and the ComfortStar indoor unit via RS485) |
| E3 | Indoor unit T2 temperature sensor fault (Applicable only when communication is established between the ComfortStar outdoor unit and the ComfortStar indoor unit via RS485) |
| E4 | Refrigerant concentration sensor fault (Applicable only when communication is established between the ComfortStar outdoor unit and the ComfortStar indoor unit via RS485) |
| E6 | Refrigerant leakage protection (Applicable only when communication is established between the ComfortStar outdoor unit and the ComfortStar indoor unit via RS485) |
| E8 | Indoor fan motor current fault (Applicable only when communication is established between the ComfortStar outdoor unit and the ComfortStar indoor unit via RS485) |
| E9 | Wired controller communication fault (Applicable only when communication is established between the ComfortStar outdoor unit and the ComfortStar indoor unit via RS485) |
| ATL | Ambient temperature out of bounds protection |
| PRH | Crankcase forced preheating for 1 hour, can not start up the system during this time |

2 Troubleshooting

2.1 Safety Precautions

The following precautions here are quite important, so be sure to follow them carefully. Read these instructions carefully before installation. Keep this manual in a handy for future preference.

Failure to adhere to all precautionary measures listed in this section may result in personal injury, damage to the unit or to property, or in extreme cases, death.



WARNING

- Indicates a potentially hazardous situation which if not avoided, could result in death or serious injury.



CAUTION

- Indicates a potentially hazardous situation which if not avoided, may result in minor or moderate injury.
- It is also used to alert against unsafe practices.

2.1.1 In case of Accidents or Emergency



WARNING

- If a gas leak is suspected, immediately turn off the gas and ventilate the area if a gas leak is suspected before turning the unit on.
- If strange sounds or smoke is detected from the unit, turn the breaker off and disconnect the power supply cable.
- If the unit comes into contact with liquid, contact an authorized service center.
- If liquid from the batteries makes contact with skin or clothing, immediately rinse or wash the area well with clean water.
- Do not insert hands or other objects into the air inlet or outlet while the unit is plugged in.
- Do not operate the unit with wet hands.



CAUTION

- Clean and ventilate the unit at regular intervals when operating it near a stove or near similar devices.
- Do not use the unit during severe weather conditions. If possible, remove the product from the window before such occurrences.

2.1.2 Information servicing(For flammable materials)



WARNING

- Use this unit only on a dedicated circuit.
- Damage to the installation area could cause the unit
- to fall, potentially resulting in personal injury, property damage, or product failure.
- Only qualified personnel should disassemble, install, remove, or repair the unit.
- Only a qualified electrician should perform electrical work. For more information, contact your dealer, seller, or an authorized service center.



CAUTION

- While unpacking be careful of sharp edges around the unit as well as the edges of the fins on the condenser and evaporator.

2.1.3 Operation and Maintenance



WARNING

- Do not use defective or under-rated circuit breakers.
- Ensure the unit is properly grounded and that a dedicated circuit and breaker are installed.
- Do not modify or extend the power cable. Ensure the power cable is secure and not damaged during operation.
- Do not unplug the power supply plug during operation.
- Do not store or use flammable materials near the unit.
- Do not open the inlet grill of the unit during operation.
- Do not touch the electrostatic filter if the unit is equipped with one.
- Do not block the inlet or outlet of air flow to the unit.
- Do not use harsh detergents, solvents, or similar items to clean the unit. Use a soft cloth for cleaning.
- Do not touch the metal parts of the unit when removing the air filter as they are very sharp.
- Do not step on or place anything on the unit or outdoor units.
- Do not drink water drained from the unit.
- Avoid direct skin contact with water drained from the unit.

- Use a firm stool or step ladder according to manufacturer procedures when cleaning or maintaining the unit.

**CAUTION**


- Do not install or operate the unit for an extended period of time in areas of high humidity or in an environment directly exposing it to sea wind or salt spray.
- Do not install the unit on a defective or damaged installation stand, or in an unsecured location.
- Ensure the unit is installed at a level position
- Do not install the unit where noise or air discharge
- Created by the outdoor unit will negatively impact the environment or nearby residences.
- Do not expose skin directly to the air discharged by the unit for prolonged periods of time.
- Ensure the unit operates in areas water or other liquids.
- Ensure the drain hose is installed correctly to ensure proper water drainage.
- When lifting or transporting the unit, it is recommended that two or more people are used for this task.
- When the unit is not to be used for an extended time, disconnect the power supply or turn off the breaker.

2.2 ATL Troubleshooting

- ATL indicates ambient temperature out of bounds protection.
- The unit stops running and will not start operating until the ambient temperature returns to the allowable temperature range, error code is displayed on the communication board.
- The allowable ambient temperature range is 5~125°F (-15~52°C).


2.3 E1/F0 Troubleshooting

- E1 indicates RS485 communication fault between outdoor unit and indoor unit(from indoor side).
- F0 indicates RS485 communication fault between outdoor unit and indoor unit(from outdoor side).
- The unit stops running and error code is displayed on the communication board



2.4 F4/F5/F6/FC/FE/E2/E3/H8 Troubleshooting

- E2 indicates indoor unit T1 temperature sensor fault
- E3 indicates indoor unit T2 temperature sensor fault
- F4 indicates ambient temperature sensor fault
- F5 indicates discharge temperature sensor fault
- F6 indicates coil temperature sensor fault
- FC indicates IPM temperature sensor fault
- FE indicates T3/TP temperature sensor loose protection
- F7 indicates T7 temperature sensor fault
- H8 indicates FE protection appears 3 times in 120 minutes can't be recovered until re-power on.
- The unit stops running and error code is displayed on the communication board




Note:

- 1) Measure sensor resistance. If the resistance is too low, the sensor has short-circuited. If the resistance is not consistent with the sensor's resistance characteristics table, the sensor has failed.
- 2) E2/E3 is applicable only when communication is established between the ComfortStar outdoor unit and the ComfortStar indoor unit via RS-485.


2.5 E4 Troubleshooting

- E4 indicates refrigerant concentration sensor fault, E4 is applicable only when communication is established between the ComfortStar outdoor unit and the ComfortStar indoor unit via RS-485
- The unit stops running and error code is displayed on the communication board




2.7 E6 Troubleshooting

- E8 indicates refrigerant leakage protection , E6 is applicable only when communication is established between the ComfortStar outdoor unit and the ComfortStar indoor unit via RS-485.
- The unit stops running and error code is displayed on the communication board.
- R32 refrigerantR32 refrigerant is a flammable gas. When the E4 fault occurs, first ensure that the ventilation around the indoor unit is good and that the refrigerant concentration is within a safe range.




2.7 E8 Troubleshooting

- E8 indicates indoor fan motor current fault, E8 is applicable only when communication is established between the ComfortStar outdoor unit and the ComfortStar indoor unit via RS-485.
- The unit stops running and error code is displayed on the communication board




2.8 E9 Troubleshooting

- E9 indicates wired controller communication fault, E9 is applicable only when communication is established between the ComfortStar outdoor unit and the ComfortStar indoor unit via RS485.
- The unit stops running and error code is displayed on the communication board




2.9 FA/FB Troubleshooting

- FA indicates EEPROM fault on the main PCB
- FB indicates EEPROM fault on the inverter module
- The unit stops running and error code is displayed on the communication board




2.10 FD Troubleshooting

- FD indicates pressure sensor fault
- The unit stops running and error code is displayed on the communication board



2.11 FF/P1/H2 Troubleshooting

- FF indicates high pressure switch fault for 20 minutes.
- P1 indicates high pressure switch fault for 4 seconds.
- H2 indicates FF protection appears 3 times in 150 minutes can't be recovered until re-power on.
- The unit stops running and error code is displayed on the communication board




2.12 F9/L0/L1 Troubleshooting

- F9 indicates AC voltage is too high or too low protection
- L0 indicates DC bus low voltage protection
- L1 indicates DC bus high voltage protection


| | |
|---|----------|
| Allowable voltage range of power source | 178~265V |
| Upper limit of DC generatrix voltage | 430V |
| Lower limit of DC generatrix voltage | 150V |

- The unit stops running and error code is displayed on the communication board




2.13 P2/H5 Troubleshooting

- P2 indicates low pressure protection in cooling mode.
- H5 indicates P2 protection appears 3 times in 240 minutes can't be recovered until re-power on.
- The unit stops running and error code is displayed on the communication board




2.14 P3 Troubleshooting

- P3 indicates over current protection
- The unit stops running and error code is displayed on the communication board




2.15 P4/H6 Troubleshooting

- P4 indicates discharge temperature protection
- H6 indicates P4 protection appears 3 times in 100 minutes can't be recovered until re-power on.
- The unit stops running and error code is displayed on the communication board.



2.16 P5 Troubleshooting


- P5 indicates T3 high temperature protection in cooling mode
- The unit stops running and error code is displayed on the communication board.




2.17 P6 Troubleshooting

- P6 indicates compressor inverter module protection.
- The unit stops running and error code is displayed on the communication board.


Situation1: P6 appears immediately when the outdoor unit is powered-on



Situation2: P6 appears immediately after the compressor starts up




Situation3: P6 appears after the compressor has been running for a period of time.




2.18 P7/PC Troubleshooting

- P7 indicates Indoor unit anti-freezing protection.
- PC indicates overwet operation protection.
- The unit stops running and error code is displayed on the communication board.
- P7/PC is applicable only when communication is established between the ComfortStar outdoor unit and the ComfortStar indoor unit via RS485.




2.19 P8 Troubleshooting

- P8 indicates IPM high temperature protection.
- The unit stops running and error code is displayed on the communication board.



2.20 P9 Troubleshooting

- P9 indicates fan motor inverter module protection
- The unit stops running and error code is displayed on the communication board.



2.21 H0 Troubleshooting

- H0 indicates Inverter module and main PCB communication error
- The unit stops running and error code is displayed on the communication board.

There is only one control PCB in the electric control box which integrates the functions of main control board and inverter module, maintenance personnel has to replace the PCB when H0 fault occurs.

2.22 The outdoor unit is displaying PRH.

- PRH indicates crankcase forced preheating for 1 hour, the unit can not start up during this time, the code is displayed on the communication board.

The purpose of preheating is to protect the compressor from damage caused by insufficient oil, and it is not a product fault. This will only occur when the unit is powered on for the first time. The installer and user simply need to wait for 1 hour until the preheating is completed, after which the unit can start up normally.

3. Temperature Sensor Resistance Characteristics

Room temperature sensor(T1), condenser coil temperature sensor(T2), condenser coil temperature sensor(T3) and outdoor ambient temperature sensor(T4) resistance characteristics.

| Temperature | R _{max} | R _{nor} | R _{min} |
|-------------|------------------|------------------|------------------|
| °C | kΩ | kΩ | kΩ |
| -25 | 49.51 | 47.92 | 46.38 |
| -24 | 46.94 | 45.46 | 44.02 |
| -23 | 44.51 | 43.13 | 41.79 |
| -22 | 42.23 | 40.94 | 39.69 |
| -21 | 40.08 | 38.88 | 37.71 |
| -20 | 38.05 | 36.93 | 35.84 |
| -19 | 36.14 | 35.09 | 34.07 |
| -18 | 34.34 | 33.36 | 32.40 |
| -17 | 32.63 | 31.72 | 30.83 |
| -16 | 31.03 | 30.17 | 29.34 |
| -15 | 29.51 | 28.71 | 27.93 |
| -14 | 28.07 | 27.33 | 26.60 |
| -13 | 26.72 | 26.02 | 25.34 |
| -12 | 25.44 | 24.78 | 24.15 |
| -11 | 24.22 | 23.61 | 23.02 |
| -10 | 23.08 | 22.51 | 21.95 |
| -9 | 21.99 | 21.46 | 20.93 |
| -8 | 20.96 | 20.46 | 19.97 |
| -7 | 19.99 | 19.52 | 19.06 |
| -6 | 19.06 | 18.63 | 18.20 |
| -5 | 18.19 | 17.78 | 17.38 |
| -4 | 17.36 | 16.98 | 16.61 |
| -3 | 16.57 | 16.22 | 15.87 |
| -2 | 15.83 | 15.49 | 15.17 |
| -1 | 15.12 | 14.81 | 14.50 |
| 0 | 14.45 | 14.16 | 13.87 |
| 1 | 13.81 | 13.54 | 13.27 |
| 2 | 13.20 | 12.95 | 12.70 |
| 3 | 12.63 | 12.39 | 12.15 |
| 4 | 12.08 | 11.85 | 11.64 |
| 5 | 11.56 | 11.35 | 11.14 |
| 6 | 11.06 | 10.87 | 10.67 |
| 7 | 10.59 | 10.41 | 10.23 |
| 8 | 10.14 | 9.97 | 9.80 |
| 9 | 9.71 | 9.56 | 9.40 |
| 10 | 9.31 | 9.16 | 9.01 |
| 11 | 8.92 | 8.78 | 8.65 |
| 12 | 8.55 | 8.42 | 8.30 |
| 13 | 8.20 | 8.08 | 7.96 |
| 14 | 7.86 | 7.75 | 7.64 |
| 15 | 7.55 | 7.44 | 7.34 |

| Temperature | R _{max} | R _{nor} | R _{min} |
|-------------|------------------|------------------|------------------|
| °C | kΩ | kΩ | kΩ |
| 16 | 7.24 | 7.14 | 7.05 |
| 17 | 6.95 | 6.86 | 6.77 |
| 18 | 6.67 | 6.59 | 6.50 |
| 19 | 6.41 | 6.33 | 6.25 |
| 20 | 6.15 | 6.08 | 6.01 |
| 21 | 5.91 | 5.85 | 5.78 |
| 22 | 5.68 | 5.62 | 5.56 |
| 23 | 5.46 | 5.40 | 5.35 |
| 24 | 5.25 | 5.20 | 5.14 |
| 25 | 5.05 | 5.00 | 4.95 |
| 26 | 4.86 | 4.81 | 4.76 |
| 27 | 4.68 | 4.63 | 4.58 |
| 28 | 4.51 | 4.46 | 4.41 |
| 29 | 4.34 | 4.29 | 4.24 |
| 30 | 4.18 | 4.13 | 4.08 |
| 31 | 4.03 | 3.98 | 3.93 |
| 32 | 3.89 | 3.84 | 3.79 |
| 33 | 3.75 | 3.70 | 3.65 |
| 34 | 3.61 | 3.56 | 3.52 |
| 35 | 3.48 | 3.44 | 3.39 |
| 36 | 3.36 | 3.31 | 3.27 |
| 37 | 3.24 | 3.20 | 3.15 |
| 38 | 3.13 | 3.08 | 3.04 |
| 39 | 3.02 | 2.97 | 2.93 |
| 40 | 2.91 | 2.87 | 2.83 |
| 42 | 2.72 | 2.67 | 2.63 |
| 43 | 2.63 | 2.58 | 2.54 |
| 44 | 2.54 | 2.49 | 2.45 |
| 45 | 2.45 | 2.41 | 2.37 |
| 46 | 2.37 | 2.33 | 2.29 |
| 47 | 2.29 | 2.25 | 2.21 |
| 48 | 2.21 | 2.17 | 2.13 |
| 49 | 2.14 | 2.10 | 2.06 |
| 50 | 2.07 | 2.03 | 1.99 |
| 51 | 2.00 | 1.97 | 1.93 |
| 52 | 1.94 | 1.90 | 1.86 |
| 53 | 1.88 | 1.84 | 1.80 |
| 54 | 1.82 | 1.78 | 1.74 |
| 55 | 1.76 | 1.72 | 1.69 |
| 56 | 1.70 | 1.67 | 1.63 |
| 57 | 1.65 | 1.61 | 1.58 |

| Temperature | R _{max} | R _{nor} | R _{min} |
|-------------|------------------|------------------|------------------|
| °C | (kΩ) | (kΩ) | (kΩ) |
| 58 | 1.60 | 1.56 | 1.53 |
| 59 | 1.55 | 1.51 | 1.48 |
| 60 | 1.50 | 1.46 | 1.43 |
| 61 | 1.45 | 1.42 | 1.39 |
| 62 | 1.41 | 1.37 | 1.34 |
| 63 | 1.36 | 1.33 | 1.30 |
| 64 | 1.32 | 1.29 | 1.26 |
| 65 | 1.28 | 1.25 | 1.22 |
| 66 | 1.24 | 1.21 | 1.18 |
| 67 | 1.21 | 1.18 | 1.15 |
| 68 | 1.17 | 1.14 | 1.11 |
| 69 | 1.13 | 1.11 | 1.08 |
| 70 | 1.10 | 1.07 | 1.05 |
| 71 | 1.07 | 1.04 | 1.02 |
| 72 | 1.04 | 1.01 | 0.98 |
| 73 | 1.01 | 0.98 | 0.96 |
| 74 | 0.98 | 0.95 | 0.93 |
| 75 | 0.95 | 0.92 | 0.90 |
| 76 | 0.92 | 0.90 | 0.87 |
| 77 | 0.90 | 0.87 | 0.85 |
| 78 | 0.87 | 0.85 | 0.82 |
| 79 | 0.85 | 0.82 | 0.80 |
| 80 | 0.82 | 0.80 | 0.78 |
| 81 | 0.80 | 0.78 | 0.75 |
| 82 | 0.78 | 0.75 | 0.73 |
| 83 | 0.75 | 0.73 | 0.71 |
| 84 | 0.73 | 0.71 | 0.69 |
| 85 | 0.71 | 0.69 | 0.67 |
| 86 | 0.69 | 0.67 | 0.65 |
| 87 | 0.68 | 0.66 | 0.64 |
| 88 | 0.66 | 0.64 | 0.62 |
| 89 | 0.64 | 0.62 | 0.60 |
| 90 | 0.62 | 0.60 | 0.58 |
| 91 | 0.61 | 0.59 | 0.57 |
| 92 | 0.59 | 0.57 | 0.55 |
| 93 | 0.57 | 0.56 | 0.54 |
| 94 | 0.56 | 0.54 | 0.52 |
| 95 | 0.54 | 0.53 | 0.51 |
| 96 | 0.53 | 0.51 | 0.50 |
| 97 | 0.52 | 0.50 | 0.48 |
| 98 | 0.50 | 0.49 | 0.47 |
| 99 | 0.49 | 0.47 | 0.46 |
| 100 | 0.48 | 0.46 | 0.45 |

Compressor exhaust temperature sensor (T5) resistance characteristics.

| Temperature (°C) | Resistance (kΩ) |
|------------------|-----------------|------------------|-----------------|------------------|-----------------|------------------|-----------------|
| -20 | 542.7 | 20 | 68.66 | 60 | 13.59 | 100 | 3.702 |
| -19 | 511.9 | 21 | 65.62 | 61 | 13.11 | 101 | 3.595 |
| -18 | 483 | 22 | 62.73 | 62 | 12.65 | 102 | 3.492 |
| -17 | 455.9 | 23 | 59.98 | 63 | 12.21 | 103 | 3.392 |
| -16 | 430.5 | 24 | 57.37 | 64 | 11.79 | 104 | 3.296 |
| -15 | 406.7 | 25 | 54.89 | 65 | 11.38 | 105 | 3.203 |
| -14 | 384.3 | 26 | 52.53 | 66 | 10.99 | 106 | 3.113 |
| -13 | 363.3 | 27 | 50.28 | 67 | 10.61 | 107 | 3.025 |
| -12 | 343.6 | 28 | 48.14 | 68 | 10.25 | 108 | 2.941 |
| -11 | 325.1 | 29 | 46.11 | 69 | 9.902 | 109 | 2.86 |
| -10 | 307.7 | 30 | 44.17 | 70 | 9.569 | 110 | 2.781 |
| -9 | 291.3 | 31 | 42.33 | 71 | 9.248 | 111 | 2.704 |
| -8 | 275.9 | 32 | 40.57 | 72 | 8.94 | 112 | 2.63 |
| -7 | 261.4 | 33 | 38.89 | 73 | 8.643 | 113 | 2.559 |
| -6 | 247.8 | 34 | 37.3 | 74 | 8.358 | 114 | 2.489 |
| -5 | 234.9 | 35 | 35.78 | 75 | 8.084 | 115 | 2.422 |
| -4 | 222.8 | 36 | 34.32 | 76 | 7.82 | 116 | 2.357 |
| -3 | 211.4 | 37 | 32.94 | 77 | 7.566 | 117 | 2.294 |
| -2 | 200.7 | 38 | 31.62 | 78 | 7.321 | 118 | 2.233 |
| -1 | 190.5 | 39 | 30.36 | 79 | 7.086 | 119 | 2.174 |
| 0 | 180.9 | 40 | 29.15 | 80 | 6.859 | 120 | 2.117 |
| 1 | 171.9 | 41 | 28 | 81 | 6.641 | 121 | 2.061 |
| 2 | 163.3 | 42 | 26.9 | 82 | 6.43 | 122 | 2.007 |
| 3 | 155.2 | 43 | 25.86 | 83 | 6.228 | 123 | 1.955 |
| 4 | 147.6 | 44 | 24.85 | 84 | 6.033 | 124 | 1.905 |
| 5 | 140.4 | 45 | 23.89 | 85 | 5.844 | 125 | 1.856 |
| 6 | 133.5 | 46 | 22.89 | 86 | 5.663 | 126 | 1.808 |
| 7 | 127.1 | 47 | 22.1 | 87 | 5.488 | 127 | 1.762 |
| 8 | 121 | 48 | 21.26 | 88 | 5.32 | 128 | 1.717 |
| 9 | 115.2 | 49 | 20.46 | 89 | 5.157 | 129 | 1.674 |
| 10 | 109.8 | 50 | 19.69 | 90 | 5 | 130 | 1.632 |
| 11 | 104.6 | 51 | 18.96 | 91 | 4.849 | | |
| 12 | 99.69 | 52 | 18.26 | 92 | 4.703 | | |
| 13 | 95.05 | 53 | 17.58 | 93 | 4.562 | | |
| 14 | 90.66 | 54 | 16.94 | 94 | 4.426 | | |
| 15 | 86.49 | 55 | 16.32 | 95 | 4.294 | | |
| 16 | 82.54 | 56 | 15.73 | 96 | 4.167 | | |
| 17 | 78.79 | 57 | 15.16 | 97 | 4.045 | | |
| 18 | 75.24 | 58 | 14.62 | 98 | 3.927 | | |
| 19 | 71.86 | 59 | 14.09 | 99 | 3.812 | | |

ComfortStar®

The design and specifications are subject to change without prior notice for product improvement. Consult with the sales agency or manufacturer for details.