


# Exploded View

Model CIP18CD(I)-L

ComfortStar®



EX_ID	Spare Parts Code	Part Name(EN)	Qty.	Price	Remarks
1	12122000A92191	Panel assembly	1		
2	12100204000397	Air Filter	2		
3	17222000A58269	Display Box Subassembly	1		
3.1	17122000047923	Display Board Subassembly	1		
4	12122000024739	Cover Plate	1		
5	12122000025561	Panel Frame Assembly	1		
5.1	12122000013139	Screw Cap	1		
6	12122000004592	Front Cover of Chassis(Right)	1		
7	12122000025064	Cover Board For Wiring	1		
8	12122000025565	Louver	1		

9	15822000008720	Evaporator assembly	1		
10	12122000005538	Motor Cover	1		
11	11002015011867	Brushless DC Motor	1		
13	12622000000131	Bearing components	1		
14	12100102000131	Cross Flow Fan	1		
16	12122000028301	Chassis assembly	1		
16.1	12122000028302	Chassis assembly	1		
16.1.1	11002010000077	Stepper Motor	1		
16.1.2	12122000008961	Horizontal Louver	3		
16.1.3	12122000004612	Front Cover of Chassis(Left )	1		
16.1.4	12122000026403	Electrical Control Box Holder	1		
16.1.6	12100501000032	Drain Hose	1		
16.1.7	12122000000344	Insulated Axis	1		
16.1.9	12622000000030	Drainage plug	1		
16.3	12122000000350	Bearing Holder	1		
17	12122000012941	pipe clamp board	1		
18	12222000000026	Installation Plate	1		
19	17222000034257	Electronic control box subassembly (Mid-and low-end)	1		
19.1	12122000025621	Cover of Electronic Control Box(BMC)	1		
19.3	17122000051947	Main Control Board Subassembly	1		
19.4	11201007003424	Room Temperature Sensor	1		
19.5	11201007003447	Pipe Temperature Sensor	1		
19.6	17400401000576	Wire Joint	1		
21	17317000A66256	Remote controller	1		
24	12222000004704	pipe connect board	1		
40	12100204000685	Air Freshening Filter	1		