

Combination Piston Size

Technical Bulletin No. TB230904-01

1. The pre-install size:

Condenser Model	AHU Model	TXV	Piston Size
BAR5-18-15	LUC5-18-15	TR6-3T	Use TXV
BAR5-18-15	LUC5-24-15	TR6-3T	Use TXV
BAR5-24-15	LUC5-18-15	TR6-37	Use TXV
BAR5-24-15	LUC5-24-15		58*
BAR5-24-15	LUC5-36-15	TR6-4T	Use TXV
BAR5-30-15	LUC5-24-15		58*
BAR5-30-15	LUC5-36-15		73*
BAR5-30-15	LUC5-48-15		83*
BAR5-36-15	LUC5-24-15		58*
BAR5-36-15	LUC5-36-15		73*
BAR5-36-15	LUC5-48-15		83*
BAR5-42-15	LUC5-48-15	TR6-5T	Use TXV
BAR5-48-15	LUC5-48-15	TR6-5T	Use TXV
BAR5-48-15	LUC5-60-15		90*
BAR5-60-15	LUC5-60-15	TR6-6T	Use TXV

TECHNICAL BULLETIN

2. Combination piston size:

ODU	IDU	Piston Size	Piston Size come with unit
BAR5-61-15	LCM5-61-15	Come with TXV	
BAR5-18-15	LCM5-36-15	52	52,58,64
BAR5-24-15	LUC5-24-15	58	58
BAR5-24-15	LCM5-36-15	58	52,58,64
BAR5-30-15	LUC5-24-15	64	58
BAR5-30-15	LUC5-36-15	64	73,64,70,68
BAR5-30-15	LUC5-48-15	64	75,83
BAR5-30-15	LCM5-24-15	64	52,58
BAR5-30-15	LCM5-36-15	64	52,58,64
BAR5-36-15	LUC5-24-15	73	58
BAR5-36-15	LUC5-36-15	73	73,64,70,68
BAR5-36-15	LUC5-48-15	73	75,83
BAR5-42-15	LCM5-36-15	75	52,58,64
BAR5-42-15	LCM5-60-15	75	70,73,75,80,83
BAR5-48-15	LUC5-60-15	80	90
BAR5-48-15	LCM5-60-15	80	70,73,75,80,83
BAR5-60-15	LCM5-60-15	88	70,73,75,80,83
MAH5-18-410	LUC5-18-15	52	50
MAH5-18-410	LUC5-24-15	52	58
MAH5-18-410	LCM5-24-15	52	52,58
MAH5-18-410	LCM5-36-15	52	52,58,64
MAH5-24-410	LUC5-18-15	58	50
MAH5-24-410	LUC5-24-15	58	58
MAH5-24-410	LUC5-36-15	58	73,64,70,68
MAH5-24-410	LCM5-24-15	58	52,58
MAH5-24-410	LCM5-36-15	58	52,58,64
MAH5-30-410	LUC5-24-15	64	58
MAH5-30-410	LUC5-36-15	64	73,64,70,68

ComfortStar®

Air Conditioning & Heating Products

ODU	IDU	Piston Size	Piston Size come with unit
MAH5-30-410	LUC5-48-15	64	75,83
MAH5-30-410	LCM5-24-15	64	52,58
MAH5-30-410	LCM5-36-15	64	52,58,64
MAH5-36-410	LUC5-24-15	70	58
MAH5-36-410	LUC5-36-15	73	73,64,70,68
MAH5-36-410	LUC5-48-15	73	75,83
MAH5-36-410	LCM5-24-15	70	52,58
MAH5-36-410	LCM5-36-15	70	52,58,64
MAH5-42-410	LUC5-36-15	75	73,64,70,68
MAH5-42-410	LUC5-48-15	75	75,83
MAH5-42-410	LUC5-60-15	75	90
MAH5-42-410	LCM5-60-15	75	70,73,75,80,83
MAH5-48-410	LUC5-48-15	83	75,83
MAH5-48-410	LUC5-60-15	83	90
MAH5-48-410	LCM5-60-15	83	70,73,75,80,83
MAH5-60-410	LCM5-60-15	88	70,73,75,80,83
MAH5-18-410	CWM5-24-15	Come with TXV	
MAH5-24-410	CWM5-24-15	Come with TXV	
MAH5-24-410	CWM5-30-15	Come with TXV	
MAH5-30-410	CWM5-30-15	Come with TXV	
MAH5-30-410	CWM5-24-15	Come with TXV	
MAH5-30-410	CWM5-36-15	Come with TXV	
MAH5-36-410	CWM5-36-15	Come with TXV	
MAH5-36-410	CWM5-30-15	Come with TXV	
BAR5-18-15	CWM5-24-15	Come with TXV	
BAR5-24-15	CWM5-24-15	Come with TXV	
BAR5-24-15	CWM5-30-15	Come with TXV	
BAR5-30-15	CWM5-30-15	Come with TXV	
BAR5-30-15	CWM5-24-15	Come with TXV	
BAR5-30-15	CWM5-36-15	Come with TXV	

TECHNICAL BULLETIN

ODU	IDU	Piston Size	Piston Size come with unit
BAR5-36-15	CWM5-36-15	Come with TXV	
BAR5-36-15	CWM5-30-15	Come with TXV	
BAR5-18-15	LUC5-18-15+TXV	Install TXV in Field	50
BAR5-18-15	LUC5-24-15+TXV	Install TXV in Field	58
BAR5-18-15	LCM5-24-15+TXV	Install TXV in Field	52,58
BAR5-24-15	LUC5-18-15+TXV	Install TXV in Field	50
BAR5-24-15	LUC5-36-15+TXV	Install TXV in Field	73,64,70,68
BAR5-24-15	LCM5-24-15+TXV	Install TXV in Field	52,58
BAR5-36-15	LCM5-36-15+TXV	Install TXV in Field	52,58,64
BAR5-42-15	LUC5-48-15+TXV	Install TXV in Field	75,83
BAR5-48-15	LUC5-48-15+TXV	Install TXV in Field	75,83
BAR5-60-15	LUC5-60-15+TXV	Install TXV in Field	90
MAH5-42-410	LCM5-36-15+TXV	Install TXV in Field	52,58,64
MAH5-60-410	LUC5-48-15+TXV	Install TXV in Field	75,83
MAH5-60-410	LUC5-60-15+TXV	Install TXV in Field	90
MAH5-18-410	CWM-24-14	Come with TXV	
MAH5-24-410	CWM-24-14	Come with TXV	
MAH5-30-410	CWM-24-14	Come with TXV	
BAR5-18-15	CWM-24-14	Come with TXV	
BAR5-24-15	CWM-24-14	Come with TXV	
BAR5-30-15	CWM-24-14	Come with TXV	