


Exploded View

Model

BAH5-42-15

ComfortStar®



EX_ID	Spare Parts Code	Part Name(EN)	Qty.	Price	Remarks
1.1	12223000A02870	Side panel assembly	2		
1.2	12223000A02929	Side panel assembly	2		
2	12223000002572	Side panel assembly	3		
3	12200104000038	Fan	1		
4	11301805000012	Motor Mounting bolt	4		
5	11002015015328	Brushless DC Motor	1		
6	12123000000464	Motor installation board ass'y	1		
7	12227700003729	Top Cover	1		
8	11301002000001	Stainless steel bolts	8		

9	12223000001094	Top cover assembly	1		
10	15823000004786	Condenser ass'y	1		
10.1	15823000004787	Condenser	1		
10.2	15123000010945	Condenser inlet pipe ass'y	1		
10.3	15423000004597	Condenser outlet pipe ass'y	1		
11	15423000004599	Throttle assembly	1		
11.1	15500210000388	Throttle	1		
12	15423000003178	Stop valve ass'y	1		
12.1	15500206000018	Block valve	1		
13	15423000005731	Suction pipe ass'y	1		
13.1	15427000001439	Fusible plug assembly	1		
13.2	17400516000149	Pressure switch	1		
14	15423000005723	4-way valve ass'y	1		
14.1	15123000013420	Pipe joint ass'y	1		
14.2	15423000005724	4-way valve assembly	1		
14.2.1	15500216002243	4-way valve ass'y	1		
14.2.2	17400516000032	Pressure switch	1		
14.2.3	15500206000017	Bar-Stock Service Valve	1		
15	15500508001115	Accumulator cylinder	1		
16	12223000005894	Base assembly	1		
17	11102010000412	Fixed Speed Scroll compressor	1		
18.1	12223000015849	Installation plate of electric parts subassembly	1		
18.2	17123000A03565	Outdoor main control board assembly	1		
18.3	17400103000150	Capacitor	1		
18.4	11203502000032	AC contactor	1		
19	12223000016090	Side panel assembly	1		
20	12223000A05994	Side panel assembly	1		
21	17400513003814	Discharge Temperature switch	1		
22	11201007000073	Room Temperature Sensor	1		
23	11201007000136	Pipe Temperature Sensor	1		
24	17402001000033	Crankcase electric heater	1		