


Exploded View

Model

CFU18CD(I)

ComfortStar®



EX_ID	Spare Parts Code	Part Name(EN)	Qty.	Price	Remarks
1	12122000A88532	Panel assembly	1.00		
2	12100204001559	Filter	2.00		
3	17222000A18768	Display Box Subassembly	1.00		
3.1	17122000041912	Display board subassembly	1.00		
4	12122000013131	Cover Plate	1.00		
5	12122000013179	Panel Frame Assembly	1.00		
5.1	12122000013139	Screw Cap	2.00		
6	12122000013175	Front Cover of Chassis(Right)	1.00		
7	12122000013141	Cover of Electrical Equipment Subassembly	1.00		
8	12122000013187	Louver	1.00		

9	15822000008573	Evaporator assembly	1.00		
10	12122000013176	Motor Cover	1.00		
11	11002015017672	Brushless DC Motor	1.00		
12	12122000000350	Bearing Sleeve	1.00		
13	12622000000131	Bearing Block Assembly	1.00		
14	12100102000131	Cross Flow Fan	1.00		
16	12122000013181	Chassis Assembly	1.00		
16.1	11002010000143	Stepper Motor	1.00		
16.2	12100501000032	Drain Hose	1.00		
16.3	12122000013183	Horizontal louver	1.00		
16.4	12122000013186	Front Cover of Chassis(Left)	1.00		
16.5	12122000000344	Electricity Preventing Axis	1.00		
16.6	12622000000030	Drainage plug	1.00		
17	12122000013178	Pipe Clamp Board	1.00		
18	12222000005866	Installation Plate	1.00		
19	17222000043032	Electronic control box subassembly (Mid-and low-end)	1.00		
19.4	17122000062533	Main control board subassembly	1.00		
19.6	11201007003445	Pipe Temperature Sensor	1.00		
19.7	17400401000094	Terminal	1.00		
19.9	11201007003424	Room Temperature Sensor	1.00		
20	12122000013132	Electrical Control Box Cover Subassembly	1.00		
21	17317000A65321	Remote controller	1.00		
40	12100204000685	Cold Catalyst Air Filter	1.00		
45	12122000029201	Bracket of Remote Controller	1.00		
47	17401203A00145	Indoor and Outdoor Junction Cable	1.00		