



Exploded View

Model MRH32-36 (33E)
Service code: 33E

ComfortStar®





EX_ID	Spare Parts Code	Part Name(EN)	Qty.	Price	Remarks
1	602938000003	Air Outlet Grille (Wire Mesh)			
2	601247000091	Motor Mounting Bracket			
3	602401700044	Brushless DC Motor			
4	602907200001	Axial Fan Blade(Metallic)			
5	601238000058	Top Cover Insulating Panel Assembly			
6	601258000119	Logo Fixing Plate			
7	602002100029	Logo			
8	601238000052	Stand column			
9	601238000060	Right Side Panel			
10	601238000059	Left Side Panel			
11	601238000054	Upper Side Panel			
12	601238000061	Control Board Mounting Plate Assembly			
13	601335000010	Outdoor Control Board			
14	602958000006	Radiator Cover Plate			
15	601302200004	Communication Board			

16	602404700047	Terminal Block			
17	601103400005	Wire Clamp			
18	601238000053	Lower Side Panel			
19	601403200014	Compressor			
20	602442000004	Compressor Crankcase Heater			
21	601605000017	Gas-liquid separator			
22	601238000057	Outdoor Unit Chassisn Assembly			
23	601542000009	Condensor Assembly			
23.1	601530000111	Condensor			
23.2	601630000294	Flute tube assembly			
23.3	601630000295	Distributor assembly			
24	601637000696	Four-way Valve Assembly			
24.1	601602200008	Four-way Valve(only the body)			
24.2	602410100004	Four-way Valve Coil			
24.3	602405F00005	High Pressure switch			
24.4	602301600001	Pressure sensor			
24.5	601602100003	Stop valve(Gas side)			
25	601637000705	Compressor Suction Pipe Assembly			
25.1	602405F00010	Low Pressure switch			
26	601637000701	Refrigerant Cooling Pipe Assembly			
27	601637000702	High Pressure Valve Assembly			
27.1	601602100001	Stop valve(liquid side)			
28	601637000727	Electrical Expansion Valve Assembly			
28.1	601602700001	Electrical Expansion Valve (body)			
28.2	602410100003	Electrical Expansion Valve coil			