



Exploded View

Model MRH32-60 (33G)
Service code: 33G

ComfortStar®





EX_ID	Spare Parts Code	Part Name(EN)	Qty.	Price	Remarks
1	602938000003	Air Outlet Grille (Wire Mesh)			
2	601247000017	Motor Mounting Bracket			
3	602401700044	Brushless DC Motor			
4	602907200001	Axial Fan Blade(Metallic)			
5	601238000058	Top Cover Insulating Panel Assembly			
6	601258000119	Logo Fixing Plate			
7	602002100029	Logo			
8	601238000062	Stand column			
9	601238000064	Right Side Panel			
10	601238000063	Left Side Panel			
11	601238000054	Upper Side Panel			
12	601237000157	Reactor cover			
13	602410200004	Reactor			
14	601238000078	Control Board Mounting Plate Assembly			
15	601335000015	Outdoor Control Board			

16	602958000007	Radiator Cover Plate			
17	601302200004	Communication Board			
18	602404700047	Terminal Block			
19	601103400005	Wire Clamp			
20	601238000065	Lower Side Panel			
21	601403200016	Compressor			
22	602458000006	Compressor Crankcase Heater			
23	601605000019	Gas-liquid separator			
24	601238000057	Outdoor Unit Chassisn Assembly			
25	601542000010	Condensor Assembly			
25.1	601530000112	Condensor			
25.2	601630000297	Flute tube assembly(Gas side)			
25.3	601630000296	Flute tube assembly(Liquid side)			
26	601637000731	Four-way Valve Assembly			
26.1	601602200004	Four-way Valve(only the body)			
26.2	602410100004	Four-way Valve Coil			
26.3	602405F00005	High Pressure switch			
26.4	602301600001	Pressure sensor			
26.5	601602100003	Stop valve(Gas side)			
27	601637000732	Compressor Suction Pipe Assembly			
27.1	602405F00010	Low Pressure switch			
28	601637000729	Refrigerant Cooling Pipe Assembly			
29	601637000710	High Pressure Valve Assembly			
29.1	601602100001	Stop valve(liquid side)			
30	601637000730	Electrical Expansion Valve Assembly			
30.1	601602700002	Electrical Expansion Valve (body)			
30.2	602410100003	Electrical Expansion Valve coil			