



11	22001-000321	Vane Motor	1		
12	G0301-118688	Main PCB	1		
13	10104-100014	Indoor Sensor Assembly	1		
14	11304-100063	Terminal	1		
15	41105-000427	Electrical Box	1		
16	41102-000669	Base	1		
17	41101-000224	In And Out Pipe Fixer	1		
18	22001-000726	Indoor Motor	1		
19	42003-000045	Indoor Motor Cover	1		
20	42009-000011	Drainage Hose	1		
21	41109-000019	Installation Plate	1		
22	K0304-114077	Evaporator	1		
23	42004-000002	Cross Fan	1		
24	42007-000009	Bearing Mount	1		
25	41101-000251	Bearing Mount holder	1		
26	G0401-113608	Remote Controller	1		Not shown in Explosion view
27	H1141-110076	Remote Controller supporter	1		
28	/	Indoor Carton	1		
29	A2006-000060	Left Foaming	1		
30	A2006-000059	Right Foaming	1		