


Exploded View

Model BAH32-18-15 (306)
Service code: 306

ComfortStar®



EX_ID	Spare Parts Code	Part Name(EN)	Qty.	Price	Remarks
1	602938000004	Air Outlet Grille (Wire Mesh)	1		
2	601247000091	Motor Mounting Bracket	1		
3	602401700037	Brushless DC Motor	1		before

3	602401700044	Brushless DC Motor	1		602401700044
4	602907200002	Axial Fan Blade(Metallic)	1		
5	601238000092	Top Cover Insulating Panel Assembly	1		
6	601258000119	Logo Fixing Plate	1		
7	602002100029	Logo	1		
8	601238000085	Stand column	1		
9	601238000147	Right Side Panel	1		
10	601238000146	Left Side Panel	1		
11	601238000054	Upper Side Panel	1		601238000089
12	601238000080	Control Board Mounting Plate Assembly	1		
13	601335000011	Outdoor Control Board	1		
14	602958000006	Radiator Cover Plate	1		
15	601302200003	Communication Board	1		
16	602404700047	Terminal Block	1		
17	601103400005	Wire Clamp	1		
18	601238000081	Lower Side Panel	1		
19	601403200012	Compressor	1		
20	602442000003	Compressor Crankcase Heater	1		
21	601605000017	Gas-liquid separator	1		
22	601238000051	Outdoor Unit Chassisn Assembly	1		
23	6015420A0001	Condensor Assembly	1		
23.1	601530000114	Condensor	1		
23.2	601630000299	Flute tube assembly	1		
23.3	601630000300	Distributor assembly	1		
24	601637000716	Four-way Valve Assembly	1		
24.1	601602200008	Four-way Valve(only the body)	1		
24.2	602410100004	Four-way Valve Coil	1		
24.3	602405F00005	High Pressure switch	1		
24.4	602301600001	Pressure sensor	1		
24.5	601602100003	Stop valve(Gas side)	1		
25	601637000720	Compressor Suction Pipe Assembly	1		
25.1	602405F00010	Low Pressure switch	1		
26	601637000722	Refrigerant Cooling Pipe Assembly	1		
27	601637000702	High Pressure Valve Assembly	1		

27.1	601602100001	Stop valve(liquid side)	1		
28	601642000111	One-way Valve Assembly	1		
28.1	601630000301	Main capillary	1		
28.2	601602000004	One-way Valve	1		
29	602301500059	Temperature Sensor(T3 T4 TP)	1		
30	602301500065	Temperature Sensor(T7)	1		