ComfortStar[®]

USER MANUAL OF SMART KIT

WIFI-US Series

IMPORTANT NOTE:

Read the manual carefully before installing or connecting your Smart kit(Wireless module). Make sure to save this manual for future reference.

CONTENTS

0	SPECIFICATION	1
0	PRECAUTIONS	1
	DOWNLOAD AND INSTALL APP	
4	INSTALL THE SMART KIT	3
6	USER REGISTRATION	4
6	NETWORK CONFIGURATION	6
Ð	HOW TO USE APP	17
8	SPECIAL FUNCTIONS	19

DECLARATION OF CONFORMITY

Hereby, we declare that this Smart kit is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. A copy of the full DoC is attached. (European Union products only)

1 SPECIFICATION

Model: WIRELESS Standard: IEEE 802. 11b/g/n Antenna Type: Printed PCB Antenna Frequency Band: 2400-2483.5MHz Operation Temperature:0°C~45°C/32°F~113°F Operation Humidity: 10%~85% Power Input: DC 5V/300mA Maximum TX Power: <20dBm

2 PRECAUTIONS

- Applicable system: iOS, Android.
- Please keep you APP up to date with the latest version.
- Due to special situation may be occurred, we explicitly claims below: Not all of the Android and iOS system are compatible with APP. We will not be responsible for any issue as a result of the incompatibility.

Wireless safety strategy Smart kit only support WPA-PSK/WPA2-PSK encryption and none encryption. WPA-PSK/WPA2-PSK encryption is recommended.

Cautions

- Due to different network situation, control process may return time-out sometimes. If this situation occurs, the display between board and App may not be the same, please do not feel confused.
- Smart Phone camera needs to be 5 million pixels or above to make sure scan QR code well.

- Due to different network situation, sometimes, request time-out could happen, thus, it is necessary to do network configuration again.
- The APP system is subject to update without prior notice for product function improvement. The actual network configuration process may be slightly different from the manual, the actual process shall prevail.
- Please Check The Service Website For More information.

3 DOWNLOAD AND INSTALL APP

<u>CAUTION</u>: The following QR Code is only available for downloading APP. It is totally different with the QR code packed with SMART KIT.






- Android Phone users: scan Android QR code or go to google play, search "Comfortstar" app and download it.
- iOS users: scan iOS QR code or go to APP Store, search "Comfortstar" app and download it.
- Please Search Comfortstar in google play or AppStore.

4 INSTALL THE SMART KIT(wireless module)

- Remove the protective cap of the smart kit (wireless module)
- ② Open the front panel and insert the smart kit (wireless module) into the reserved interface.
- ③ Attach the QR code packed with Smart kit (wireless module) to the side panel of the machine, ensure it is convenience to be scanned by the mobile phone. Alternatively, user can take picture of the QR Code and save it into their own phones.





<u>WARNING</u>. This interface is only compatible with SMART KIT (wireless module) provided by the manufacturer.

5 USER REGISTRATION

- Please ensure your mobile device is connected to Wireless router. Also, the Wireless router has already connected to Internet before doing user registration and network configuration.
- It is better to log in your email box and active your registration account by clicking link in case you forget the password. You can log in with the third party accounts.





Android

iOS

① Click "Create Account



② Enter your email address and password, and then click "Register"



6 NETWORK CONFIGURATION

Cautions

- It is necessary to forget any other around network and make sure the Android or iOS device just connect to the Wireless network you want to configure.
- Make sure the Android or iOS device Wireless function works well and can be connected back to your original Wireless network automatically.

Kindly reminder:

User must finish all the steps in 8 minutes after powering on air conditioner, otherwise you need to power on it again.

- Using Android or iOS device to do network configuration
- Make sure your mobile device has already been connected to the Wi-Fi network which you want to use. Also, you need to forget other irrelevant Wi-Fi network in case it influences your configuration process.
- Disconnect the power supply of AC.
- Connect the power supply of AC, and continuously press the "LED DISPLAY" or "DO NOT DISTURB" button seven times in 10 seconds.
- When the AC displays "AP", it means that the AC Wi-Fi has already entered into "AP" mode.


Note:

There are two ways to finish the network configuration:

- Network configuration by Bluetooth scan
- Network configuration by select appliance type

Network configuration by Bluetooth scan

Note: Make sure the bluetooth of your mobile device is working.



0

9:41	all 🕆 🔳
Select Appliance Type	
Split-type AC	•
Portable AC	•
Window AC	5
Humidifier	5
Dehumidifier	5
Air to water	5
Note:No need to scan QR code to complet configuration	ė
Scan for nearby devices	
Make sure Bluetooth is working.	
Smart.devices Found: (Cales to Add)	
000	0
Split-Type Ac Window Ac Window A	le Winds

(3) Wait smart devices to find, (4) Select home Wi-Fi, then click to add it

8

9:41		
<		
0	Split-type AC	
0	Portable AC	
0	Window AC	
0	Humidifier	
0	Dehumidifier	
0	Air to water	
	Scan for nearby devices	
Bac	sk Start Configuration	
Phinese	adect family WLAN and enter the passening	~
	Smart-Pro ?	
۵	Please entir pastworth	

enter the password

9:4		
<		
0	Split-type AC	
0	Portable AC	
0	Window AC	
0	Humidifiər	
0	Dehumidifier	
0	Air to water	
	Scan for nearby devices	
Make	sure Bluetooth is working.	
-	Cancel)
85%		
The	device is connecting to the network	
E) M	ait connecting to the	~

network

Name: AC_XXXX 🗳 ОК

6 Configuration Success, you can modify the default name.

9:41	al 🗢 🖿
< Device Name	Save
Recommended Name:	
Dining Room	~
Kitchen	
Master bedroom	
Children bedroom	
Guest bedroom	
Custom Name:	



You can choose an existing name or customize a new name.


A

Bluetooth network configuration is successful, now you can see the device in the list. Network configuration by select appliance type :

		-
<	Select Appliance Type	
	Split-type AC	>
0	Portable AC	>
0	Window AC	>
0	Humidifier	>
0	Dehumidifter	>
0	Air to water	>
	No need to scan QR code to complete juration	
	Scan for nearby devices	
Make sure Bluetooth is working.		


 If the bluetooth network cofiguration is failure, please select the appliance type.

11



(2) please follow the above steps to enter "AP" mode.





③ Choose the network configuration method. (4) Choose the "Scan the QR code" method.

NOTE: Steps ③ and ④ are applicable to Android system only. iOS system does not need these two steps.



(5) When choose the "Manual (6) Please enter password Setup" method(Android). Connect to the wireless network(iOS)



- Network configuration is successful
- Onfiguration Success, you can see the device in the list.

NOTE:

- When finishing network configuration, APP will display success cue words on the screen.
- Due to different internet environment, it is possible that the device status still display "offline". If this situation occurs, it is necessary to pull and refresh the device list on the APP and make sure the device status become "online". Alternatively, user can turn off the AC power and turn on it again, the device status will become "online" after few minutes.

7 HOW TO USE APP

Please ensure both your mobile device and air conditioner are connected to the Internet before using app to control the air conditioner via internet, please follow the next steps:



① Click " Sign in "

2 Choose the air conditioner.

			all 🕈 🗖
	 Living room ••• Outcor 28' Indeer 28' 		
			\$
			Fan
	24	 1° ⊕	
	٢)	
4	٩		0
↓ 3whg			

(3) Thus, user can control air conditioners on/off status, operation mode, temperature, fan speed and so on.

NOTE:

Not all the function of the APP is available on air conditioner. For example: ECO, Turbo, Swing function, please check the user manual to find more information.

8 SPECIAL FUNCTIONS

Schedule

Weekly, user can make an appointment to turn on or off AC on specific time. User also can choose circulation to keep the AC under schedule control every week.

19

9.41	al 🗢 🖿
< Function	
Express run setting	26°C Auto 🐌
Schedules	>
Sleep	Þ
Geolocation	ON 🐌
Check	Þ
Units T	C
Information	
Share QR code	Þ
Delete	

9:41			ad 🕈 🖿
	2	4H 1	25
	10	05	
	11	06	On
	12	07	Off
Repeat			Mon.Thur. >
Settings			Cool 17℃ High >
Label			Unnamed >
	-	_	-

	al 🕆 🖿
Commonly used:	
Every day	~
Weekdays	
Only once	
Custom:	
Monday	
Tuesday	
Wednessday	
Thursday	
Friday	
Saturday	
Sunday	
_	_

Sleep

User can customize their own comfortable sleep by setting target temperature.



Check

User can simply check the AC running status with this function. When finishing this procedure, it can display the normal items, abnormal items, and detail information.


9:41	
	Check
	Scanning
	312 🗸 312 🗸 al 0 🗸
	Done
_	

Share Device

The air conditioner can be controlled by multi-users at the same time by Share Device function.

9.41	9:41 und ❤ ■ < Share QR code
Express run setting 28°C Auto 🐌	
Schedules >	
Sleep	
Geolocation ON D	
Check D	
Units 'F C	
Information >>	
Share QR code	
Delete	Now please ask your family to use APP on their own moble phones to scan this QR code and share this device to them.
① Click "Shared QR o	code" ② QR code display.





- ③ The other users must log ④ Now the others can in "Nethome Plus" app first, then click "Add Share Device" on their own mobile, then ask them to scan the QR code.
 - add the shared device



CAUTIONS:

For models of WIFI-US: FCC ID:2AS2HMZNA21 IC:24951-MZNA21

This device complies with Part 15 of the FCC Rules and it contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Only operate the device in accordance with the instructions supplied.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 20cm (8 inches) during normal operation.

25

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device. pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: --Reorient or relocate the receiving antenna.

- --Increase the separation between the equipment and receiver.
- --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- --Consult the dealer or an experienced radio/TV technician for help.

Company will not be liable for any issues and problems caused by Internet, Wireless Router and Smart Devices. Please contact the original provider to get further help.